



TSAR BOMBA

WATCH INSTRUCTION MANUAL

*Our mission is to build a portfolio of customized innovative products and services for international markets, fulfill customer needs by providing them high quality innovative products.*

*Flexibility in sourcing, competitive prices and on-time deliveries sustain our reputation as a reliable, customer-oriented, dynamic player in the market. Achieve profitable growth, operational and organizational excellence without compromising our values and business ethics.*

THANK YOU FOR CHOOSING AN TSAR BOMBA TIMEPIECE



TSAR BOMBA

## CONTENTS

3 TYPES OF WATCHES.....	1
DISPLAYS AND BUTTONS.....	2
TIME/CALENDAR SETTINGS.....	3
HOW TO CHANGE THE STRAP.....	3
USING THE STOPWATCH.....	4
DAILY CARE.....	5

# 3 TYPES OF WATCHES

## QUARTZ WATCHES

A Quartz Watch is battery powered and does not require winding. Eventually the battery will need to be replaced.

## AUTOMATIC WATCHES

An Automatic Watch is a mechanical watch that winds itself and does not require a battery. When worn daily, the movement of your wrist causes the mainspring to wind progressively, eliminating the need for additional winding. To start your automatic, you can hand wind it by rotating the crown clockwise a number of turns while in its normal operating position (screw down crowns will need to be unscrewed first), or by swinging it side to side for 30 seconds. We recommend housing an automatic in a watch winder box.

## MANUAL WIND WATCHES

A Manual Wind Watch is a mechanical watch that does not require a battery, but can only be wound by hand. To wind it, turn the crown clockwise while it is in its normal operating position until you feel resistance. This type of watch should be wound daily.

# DISPLAYS AND BUTTONS

## FUNCTION DESCRIPTION



**MODEL : TB8211Q**

**BATTERY : SR927SW**

**MOVEMENT: Seiko TMI YM92**

# TIME/CALENDAR SETTINGS

## TIME SETTINGS

1. Pull the crown out to the 2nd Click Position.
2. Turn the crown to set hour and minute hands.
3. After the time has been set, push the crown back to the Normal position.

## CALENDAR SETTINGS

1. Pull the crown out to the 1st Click Position.
2. Turn the crown clockwise to set the date.

\*If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change on the following day.

3. After the date has been set, push the crown back to the Normal position.

# HOW TO CHANGE THE STRAP

1. Use a tool to press the ① position.
2. Now, slide the strap to remove.
3. Align the chute and slide the strap.

\*Video presentation: <https://www.youtube.com/watch?v=0lpB5VcVhGc>

# USING THE STOPWATCH

This stopwatch is able to measure and display time in 1/1 second united up to maximum of 30 minutes.

Stopwatch will stop automatically after running continuously for 30 minutes.

## MEASURING TIME WITH THE STOPWATCH

1. Press button "A" to start the stopwatch.
2. The stop watch can be started and stopped each time button "A" is pressed.
3. Pressing button "B" resets the stopwatch and stopwatch minute and second hands return to their Zero positions.



## STOPWATCH RESET (INCL.AFTER REPLACING BATTERY)

This procedure should be performed when the stopwatch second & minute hand does not return to the Zero position.

1. Pull the crown out to the 2nd Click Position.
  2. Press the button "A" to set the stopwatch second hand forward. Press the button "B" to set the stopwatch second hand back.
- \* The stopwatch minute hand is synchronized with stopwatch second hand.
  - \*The stopwatch second hand can be advanced rapidly by continuously pressing button "A" or "B".
3. Once the both hands been zeroed, reset the time and return the crown to its normal position.