

arlo

Quick Start Guide

Video Doorbell (2nd Generation)
and Chime 2

December 2023



201-50739-01

Get Started

For the best experience: We recommend you fully charge your battery before setup. Access the charging port by using the included Release Pin to remove the Mounting Plate (see page 3). The LED on the front of the video doorbell will turn solid blue when 100% charged.

- 1 Download the Arlo Secure App:




Or go to arlo.com/app/secure/


- 2 To start setup, tap **Devices** and then **(+)**, and select **Doorbells & Chimes > Video Doorbell 2nd Generation** and follow the prompts.

- 3 After the doorbell is setup, go to **Devices** then tap **(+)**. Select **Doorbells & Chimes > Chimes > Chime 2** and follow the prompts.


What's in the box



Arlo Video Doorbell
& Mounting Plate



Angled Bracket
(Optional)



Chime 2



Wire Extension
Kit



Release Pin




USB Charging
Cable



Screw Kit

Get to know your Video Doorbell



Use your Release Pin to remove the Mounting Plate to access the Pairing Button and Charging Port.

Need help?

We are here for you.

Visit www.arlo.com/support for quick answers and:

- How-to videos
- Troubleshooting tips
- Additional support resources

© Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. App Store is a service mark of Apple Inc. Google Play and the Google Play logo are trademarks of Google LLC. Any other trademarks are for reference purposes.

For regulatory compliance information including the EU Declaration of Conformity, visit www.arlo.com/about/regulatory/.

Arlo Technologies Intl. Ltd
Ground Floor, Building 3
University Technology Centre
Curraheen Road, Cork T12 EF21 Ireland

Arlo Technologies UK Limited
280 Bishopsgate
London, EC2M 4RB

Arlo Technologies, Inc.
2200 Faraday Avenue, Suite 150
Carlsbad, CA 92008 USA

