



ntroduction

Welcome to the Wings True Wireless Generation with the all new Wings Phantom 500. We hope you are as excited as us to feel and flaunt your latest soundwear.

But before you dive right in, we strongly recommend going through this user manual thoroughly as it contains important technical information to ensure you have a seamless audio experience with us. Once you are done reading the manual, we are sure you will be all set to

FEEL IT! FLAUNT IT!

What's In The Box

- 6x Ear Cushions
- 2x Bluetooth Farphones 1x User Manual 1x Portable Charging Case 1x Type-C Charging Cable
- Step 1: Make sure your charging case is charged up Simply open the lid of the charging case and earbuds will power ON and enter pairing mode
 - The cool blue light of one of the earbuds will be flashing blue. This indicates that the earbuds are ready to pair with your device. Step 2: Tap "Wings Phantom 500" from the smartphone's Bluetooth menu. There's a voice prompt after successful connection. This will indicates that
 - device and are ready to use. Step 3: Congratulations! You are now connected and
 - can start playing media.

Note : In case you do not connect to any device within 5 minutes of entering pairing mode, then both earbuds will be automatically power off. Please put the earbuds back into the case and repeat the process to pair.

earbuds are successfully connected with your

How To Pair Touch Controls Usage

- Play/Pause: Double touch the sensor on one earbud to pause music. Double touch on again on any one earbuds to resume playing music. Changing Songs: Triple tap right earbuds to go to the
- next song and triple tap on left earbuds for to go to previous song.
- Adjusting Volume: Single touch the sensor on the left earbud to decrease volume, and single touch the right earbud to increase volume.
- Siri/Google Assistant: Long press for 2 seconds on right earbud to activate voice assistant.
- Game Mode: Long press for 2 seconds on the left earbud to turn ON gaming mode, the earbuds will do breathing light effect along with a voice prompt. long press for 2 second on the left earbuds again to turn OFF gaming mode.

- Answer Incoming Call: Tap left or right earbuds once
- Hang Up Ongoing Call: Tap left or right earbuds again
- ones to end the ongoing call. Reject Incoming Call: Long press for 2 second on left

Earphones completely charge: When the earphones are completely charged, the Blue light on the earphones will turn OFF.

Resetting The Device

Please follow the below steps when you see 2 "Wings Phantom 500" in your bluetooth device menu on your mobile or you can hear music through only 1 earbud. This means the left and right earbuds have not

- Step 1: Disconnect the earbuds and remove "Wings Phantom 500" from the list of paired devices on vour mobile.
- times quickly to clear the pairing data, and
- Step 3: Put them black into charge case, and the "Wings Phantom 500" ready to use on auto
- Reset process is now complete and you will be able to hear music through both earbuds.

- autopaired with each other:
- Step 2: Touch the sensor on either of the earbuds for 5 then turn it OFF
- ON & auto pairing.
- volume may accelerate battery consumption)

Talk Time: 6-7 hours Eaphones ChargingTime: about 1.5 hour Charging Time for the headest: about 2.8 times Charging Box Time: 1 hour for charging box Product Weight: Earphones4.5g, Charging case41g Size Of Earbuds & Charging Case: Earphones 39.67*

Please read below suggestions in order to helping prolong the product lifespan and clearly understand

the warranty clauses: Keep the product dry, do not put it in humid

Safety And Maintenance

- conditions to avoid short circuit. Do not expose it to the peak sun or high heat for
- extended period of time as this will short lifespan of electronic components, damage battery and deform some plastic parts.
- Do not put it in cold circumstance to avoid damage to PCB board
- Do not attempt to dismantle the product, as it
- maybe unsafe especially for non-professionals. Do not use chemical products, detergent, oily liquids
- to clean the item.
- · Do not scratch the surface with sharp items to avoid damaging the case and appearance.
- Do not charge the case for more than 5 hours to
- avoid loss in battery life.
- Avoid hearing music at maximum volume for long. periods of time as this can affect your hearing and is not advisable.

Note: Any damage to the product that is not manufacturing defect will lead to warranty being rendered null and void. Therefore, please take utmost care of your product.



to earbuds the incoming call.

or right earbuds to reject the incoming call.

Charging The Case

the packaging to charge the case

Charging The Earbuds

case and earbuds.

will turn OFF.

after every 5 seconds.

Note: Please only use a 5V adapter to charge the case

as higher voltage adapters can destroy the battery of

Please connect the charging case with charging

adapter via usb Type-C cable, which is included in

The Cool blue LED on charging case will began to

Once the case is completely charged, the Lights

Earphones Low Battery: When the charging on

earphones is low, you will hear a low battery voice

prompt. The Cool blue lights on the earbuds will flash

Charging Earphones: Place the earphones inside the

case to charge them, the blue light on earphones will

turn ON indicating that the earphones are charging.

flash; this indicates that the case is charging.

Technical Specifications

Bluetooth Version: V5.1+BR+EDR+BLE

Frequency Response: 20Hz-20KHz

Microphone Specifications: 2718

Earphones Battery Capacity: 40mAh.

Working Frequency: 2.402GHz-2.480GHz

Sensitivity: 114dB ± 3dBS.P.L at 1mW/1000Hz

Charging Case Battery Capacity: 300mAh,

Speaker Impedance: 32Ω± 15% at 1mW/ 1000Hz

Effective Distance: 15m(in an ideal environment

Playing Time: 6.7-8hours(High quality music and

22.24*26.92mm, charging case 65.1*53.3*32.3mm

Bluetooth Model: GT96

Bluetooth Decoding: SBC

Speaker Size: 10mm

Mic Sensitivity: -42±1dB

without any large obstacles)

Bluetooth Solutions: JL6976D8





