

WINGS FLOBUDS 200

Truly Wireless Earbuds



USER MANUAL



PROUDLY MADE IN INDIA

INTRODUCTION

Wings is India's fastest growing audio, smart watches and accessories brand catering to the youth. Wings was recognised as the most **Prestigious Rising Brand Of Asia 2021-2022** by **BARC Asia** in the gaming lifestyle accessories category.

Wings is on a mission to create a pop culture led brand that the youth is proud to own and **Nodwin, a subsidiary of Nazara Technologies**, has a strategic investment in alignment with the long term vision.

But before you dive right in, we strongly recommend going through this user manual thoroughly as it contains important technical information to ensure you have a seamless audio experience with us. After you're done with reading the manual, get ready to go to the next level with Wings !

WHAT'S IN THE BOX



- 2 N Pairs of Extra Ear Tips(S&L)
- 1N User Manual
- 1N Warranty Card
- 1N Type-C Charging Cable

PRODUCT LAYOUT



1. Charging Case Led Indicator
2. Earbud LED Indicator
3. Touch Control
4. Type C Charging Port
5. Microphone

HOW TO PAIR

Please make sure that the device is fully powered before using the product.

Step 1: Make sure your case is **charged up**. Open the lid of the case and take out the earbuds. The earbuds will **turn ON** and automatically enter the pairing mode, and the Left earbud LED will **flash** quickly.

Step 2: Tap **"Flobuds 200"** from the smartphone's Bluetooth menu. There is a ring prompt after a successful connection. This indicates that the earbuds are successfully connected to your device.

Step 3: Congratulations! You are now connected and can start playing media.

Note: If you do not connect to any device within 180 seconds of entering pairing mode, then both earbuds will automatically turn OFF. Please put the earbuds back into the case and repeat the process to pair.

TAP CONTROL USAGE

BASIC FUNCTION	LEFT EARBUD	RIGHT EARBUD	TOUCH CONTROLS
Volume Increase		●	Single Tap on the right earbud's touch sensor
Volume Decrease	●		Single Tap on the left earbud's touch sensor
Play/Pause Music	●●		Double Tap on any earbud's touch sensor
Next Track		●●●	Triple Tap on the right earbud's touch sensor
Previous Track	●●●		Triple Tap on the left earbud's touch sensor
Voice Assistant	<u>2sec</u>		Long Press for 2 seconds on the left earbud's touch sensor
Game Mode ON/OFF		<u>2sec</u>	Long Press for 2 seconds on the right earbud's touch sensor

● - Tap - Long press

CALL CONTROLS

CALLING FUNCTION	LEFT / RIGHT EARBUD	TOUCH CONTROLS
Answer Incoming Call	●●	Double Tap on any of the earbud's touch sensor
Hang up ongoing call	●●	While on call, Double Tap on any earbud's touch sensor
Reject incoming call	<u>2sec</u>	Long Press for 2 seconds on any earbud's touch sensor



CHARGING THE CASE

Note: Please only use a 5V/1A adapter to charge the case as higher voltage adapters can damage the battery of the case and earbuds.

Charging the Case: When the charger is connected to the charging case, the LED light will start **blinking**, indicating that the case is getting charged.

Fully Charged: When the case is completely charged, the case light will **glow static** until the charger is removed.

CHARGING THE EARBUDS

Earbuds Low Battery: Earbuds will play a jingle when the buds are low on power.

Earbuds Charging: When earbuds are placed inside the charging case, the LED light on the earbuds will turn ON indicating that the earbuds are being charged.

Earbuds Completely Charged: When the earbuds are completely charged, the LED Light on the earbuds will go OFF.

RESETTING THE DEVICE

Please follow the below steps when you see two **"Flobuds 200"** in your Bluetooth device menu on your mobile, or you can hear music through only one earbud. This means the left and right earbuds have not auto-paired with each other:

Step 1: Disconnect the earbuds and remove **"Flobuds 200"** from your mobile list of paired devices.

Step 2: Tap **five** times quickly to clear the pairing data on either of the earbuds. The **LED light** on both earbuds will **blink three** times simultaneously to show the process is completed.

Step 3: Put them back into the charging case, and **"Flobuds 200"** is ready to use. They will automatically switch on and pair instantly as well.

The Reset process is now complete and you will be able to hear music through both earbuds.

TECHNICAL SPECIFICATIONS

PARAMETERS	VALUES
Bluetooth Version:	V5.3
Effective Distance:	15m
Impedance:	32Ω
Product Weight:	44g
Speaker Size:	13mm
Total Play Time:	Upto 50 Hours
Earbuds Play Time:	Upto 10 Hours
Talk Time:	Upto 45 Hours
Standby Time:	Upto 300 Hours
Complete Charging Time:	1.5 Hours
Earbuds Charging Time:	1 Hour
Rated Input:	5V/1A
Frequency:	20Hz~20KHz
Water and Sweat Resistant:	IPX5
Charging Port:	Type-C

*T&C Apply

SAFETY & MAINTENANCE

Please read below suggestions in order to help prolong the product lifespan and clearly understand the warranty clauses:

- Please keep the product dry, do not put it in humid conditions to avoid a short circuit.
- Do not expose it to the peak sun or high heat for extended periods, as this will shorten the lifespan of electronic components, damage the battery and deform some plastic parts.
- Please do not put it in cold circumstances to avoid damage to the PCB board.
- Please do not attempt to dismantle the product, as it may be unsafe, especially for non-professionals.
- Do not use chemical products, detergents, or oily liquids to clean the item.
- Do not scratch the surface with sharp items to avoid damaging the case and appearance.
- Do not charge the product for more than 5 hours to avoid loss in battery life.
- Avoid hearing music at maximum volume for long periods as this can affect your hearing and is not advisable.

Note: Any damage to the product that is not a manufacturing defect will render the warranty null and void. Therefore, please take utmost care of your product.