

WINGS PHANTOM 380

TRUE WIRELESS GAMING EARBUDS

USER MANUAL




INTRODUCTION

Wings is India's leading gaming audio and accessories brand catering to young India. Wings was recognised as the most Prestigious Rising Brand Of Asia 2021-2022 by BARC Asia in the gaming lifestyle accessories category.

Run by a community of gamers obsessed with technology, streaming and esports, Wings is on a mission to create a gaming brand that the youth is proud to own. Nodwin Gaming, a subsidiary of Nazara Technologies has a strategic investment in Wings with a combined vision to create top notch gaming gear for the Indian gaming community.


Wings is proud to have been associated with **Battleground Masters Series (BGMS)**, a landmark esports event that was telecast, and audio partners with one of India's premier gaming organisations, **GodLike Esports**. Wings is the No. 1 gaming brand on Flipkart and Amazon currently and strives to become a globally recognizable brand over the next 3 years.

WHAT'S IN THE BOX



- 1N Pair of Earbuds
- 1N Charging case
- 2 N Pairs of Extra Ear Tips(S&L)
- 1N User Manual
- 1N Warranty Card
- 1N Type-C Charging Cable

PRODUCT LAYOUT



1. Charging LED of charging case
2. Type-C Charging Port
3. Touch Control
4. LED Indicator of Earbuds
5. Microphone 1
6. Microphone 2

HOW TO PAIR

Before queue-ing up with your squad, Pair up with us to ensure maximum victories.

Please make sure that the device is fully powered before using it.

Step 1: Make sure your charging case is charged up. Simply remove the earbuds from the charging case, and the earbuds will turn ON and automatically enter the pairing mode. The left earbud LED will flash in alternate colours quickly.

Step 2: Tap "Phantom 380" from the smartphone's Bluetooth menu. There is a ring prompt after a successful connection. This indicates earbuds are successfully connected to your device.

Step 3: Congratulations! You are now connected and can start playing media.

Note: If you do not connect to any device within 180 seconds of entering pairing mode, then both earbuds will automatically turn OFF. Please put the earbuds back into the case and repeat the pairing process.

TOUCH CONTROL

For better access and functionality during matches, use our tap controls to save on those crucial moments between games.

BASIC FUNCTION	LEFT EARBUD	RIGHT EARBUD	TOUCH CONTROLS
Volume Increase		●	Single Tap on the right earbud's touch sensor
Volume Decrease	●		Single Tap on the left earbud's touch sensor
Play/Pause Music	●●		Double Tap on any earbud's touch sensor
Next Track		●●●●	Tap on the right earbud's touch sensor for 4 times
Previous Track	●●●●		Tap on the left earbud's touch sensor for 4 times
Voice Assistant	2sec		Long Press for 2 seconds on the left earbud's touch sensor
Game Mode ON/OFF	2sec		Long Press for 2 seconds on the right earbud's touch sensor
Transparent Mode		●●●	Triple tap on the right earbud's touch sensor
ANC Mode	●●●		Triple tap on the left earbud's touch sensor

● - Tap — - Long press

CALLING CONTROLS

Use our Call control features to make swift decisions in-game and clutch up without breaking your focus.

CALLING FUNCTION	LEFT EARBUD	RIGHT EARBUD	TOUCH CONTROLS
Answer Incoming Call		●●	Double Tap on any earbud's touch sensor
Hang up calls		●●	While on call, Double Tap on any earbud's touch sensor
Reject calls	2sec		Long Press for 2 seconds on any earbud's touch sensor
Call Volume Increase		2sec	Long press on the right earbud's touch sensor for 2 seconds
Call Volume Decrease	2sec		Long press on the left earbud's touch sensor for 2 seconds

● - Tap — - Long press

CHARGING THE CASE

Our Charging Speed makes sure to leave your enemies in the dust! So Charge up and get going !!

Note: Please only use a 5V/1A adapter to charge the case as higher voltage adapters can destroy the battery of the case and earbuds.

Low Battery : When the case battery is low, The white LED on the charging case light will flash three times every 30 seconds.

Charging The Case: While charging the case, the case's ice blue lights will blink.

Earbuds Completely Charged: When the earbuds are completely charged, the lights on the earbuds will go OFF.

CALLING THE CASE

Ice blue light steady ON

White light flashes 3 times for every 30 seconds

Ice blue light blinks

WINGS SYNC APP SUPPORT

Sync up like the pros! Use these convenient features to level up your Wings Experience!

For Android:

1. Scan the QR Code & Install the "Wings Sync" app from the play store and sign up in the app.

2. Search and add the device from the "Add device" section of the app

3. While the device is getting paired, the mobile will give a pop-up of "pairing request" to connect the device with mobile. Please select on the "Pair & connect" and the device will connect successfully with the "Wings Sync" app.

Note: In case you skipped this notification or this didn't pop-up, please pair the device with the Bluetooth of the mobile manually by following the "How to Pair" section of the user manual.

For IOS:

1. Scan the QR code & Install the "Wings Sync" app from the App store and sign up in the app.

2. Search and add the device from the "Add device" section of the app. A floating notification will flash in the app saying, "The device is not connected to the system Bluetooth" click on it and go to the settings.

RESETTING THE DEVICE

On the rare occasion you might need to reset the earphones, here's a quick guide after which you can get back into the grind!

Please follow the below steps when you see "Phantom 380" in your Bluetooth device menu on your mobile, or you can hear music through only one earbud. This means the left and right earbuds have not auto-paired with each other.

Step 1: Disconnect the earbuds and remove Phantom 380 from your mobile list of paired devices.

Step 2: Tap five times quickly to clear the pairing data on either of the earbuds

Step 3: Put them back into the charging case, and "Phantom 380" is ready to use. The earbuds will automatically go into pairing mode.

The reset process is complete, and you can hear music through both earbuds.

Note: Reset the earbuds if the device cannot be added to the Wings Sync app or delete the earbud's data from the Wings Sync app.

TECHNICAL SPECIFICATIONS

PARAMETERS	VALUES
Bluetooth Version:	V5.3
Effective Distance:	15m
Impedance:	32Ω
Product Weight:	39g
Speaker Size:	13mm
Total Play Time:	Upto 50 Hours
Earbuds Play Time:	Upto 10 Hours
Talk Time:	Upto 45 Hours
Standby Time:	Upto 300 Hours
Complete Charging Time:	1.5 Hours
Earbuds Charging Time:	1 Hour
Rated Input:	5V/1A
Frequency:	20Hz~20KHz
ANC:	30dB
Water and Sweat Resistant:	IPX5
Charging Port:	Type-C

SAFETY AND MAINTENANCE

Please read below suggestions to help prolong the product lifespan and clearly understand the warranty clauses:

- Gamers need to hydrate after a long match. That is not the case with our earbuds, so, **Keep the product dry, do not put it in humid conditions to avoid a short circuit.**
- We understand you carry the fire of a gamer within you, but please, **Do not expose it to the peak sun or high heat for extended periods of time as this will shorten lifespan of electronic components, damage battery and deform some plastic parts.**
- You may be Captain Cool leader of your squad but our products work best without a cold environment, so, **Do not put it in cold circumstances to avoid damage to the PCB board.**
- We know you are tech geeks and can build your own gaming PC from scratch, but, **Do not attempt to dismantle the product, as it may be unsafe especially for non-professionals.**
- Gamers are tough and our earbuds are tougher, but please **Do not use chemical products, detergent, oily liquids to clean the item.**
- In game, the bullets and knives are the norm however, **Do not scratch the surface with sharp items to avoid damaging the case and appearance.**
- We understand your passion for power, but in this case, **Less is More, so, Do not charge the product for more than 5 hours to avoid loss in battery life.**
- Being immersed in the game is one thing, yet **Avoid hearing music at maximum volume for long periods as this can affect your hearing and is not advisable.**

Note: Any damage to the product that is not a manufacturing defect will render the warranty null and void. Therefore, please take utmost care of your product.

*T&C Apply