

## **INTRODUCTION** (

Welcome to the Wings True Wireless Generation with the all new "Winas Phantom 500". We hope you are as excited as us to feel and flaunt your latest soundwear. But before you dive right in, we strongly recommend going through this user manual thoroughly as it contains important technical information to ensure you have a seamless audio experience with us. Once you are done reading the manual, we are sure you will be all set to

### BE THE SICKEST IN THE GAME!

It's not just a tagline, it's who we are. Esports and Gaming has

perfect headshot.

But more than anything - We are PROUD to be gamers. Just like vou.

Let's Go!

2x Bluetooth

truly arrived in India and at Winas, we celebrate the modern Indian gamer with products that reflect the same drive and finesse that goes into the sport.

We are a community of passionate of gaming enthusiasts with the highest standards and the ambition to be the best. It is the same passion with which we add style and performance to every Winas product so you can elevate your game and enjoy the rush of that

## WHAT'S IN THE BOX

# ---4x Extra Ear Tips

1x User Manual

1x Type-C

Charging Cable

1x Warranty Card

2. Type-C Input

PRODUCT LAYOUT | | | | |

3. Earbuds Touch Control

4. Microphone

## the process to pair

## HOW TO PAIR

Step 1: Make sure your charging case is charged up. Simply open the lid of the charging case and take out the earbuds. The earbuds will turn ON and will automatically enter the pairing

Step 2: Tap "Wings Phantom 500" from the smartphone's Bluetooth menu. There is a voice prompt after successful connection. This indicates earbuds are successfully connected to



Note: In case you do not connect to any device within 5 minutes of entering pairing mode, then both earbuds will be automatically power OFF. Please put the earbuds back into the case and repeat

your device.

TOUCH CONTROL USAGE R

Double Tap the sensor on any one earbud

----Changing Songs

Adjusting Volume

Siri/Google Assistant

activate voice assistant.

turn aamina mode OFF.

Triple Tap on right earbud to go to next song

Single Tap on right earbud to increase volume.

Single Tap on left earbud to decrease volume.

Long press for 2 seconds on left earbud to

Gaming Mode: Long press for 2 seconds

the right earbud to turn gaming mode ON,

The earbuds will do breathing light effect.

Long press for 2 sec the right earbud again to

Triple Tap on left earbud to go to previous

to pause music. Double Tap on any sensor

again on any one earbud to resume

Play/Pause

playing music.

## CALL CONTROLS

Answer Incoming Call: Double Tap the sensor on any earbud to answer incoming call.

Hang up Ongoing call: While on call, Double Tap the sensor on any earbud to hang up the call.

Reject Incoming Call: Long press on any earbud for 2 seconds to reject incoming call.

3rd Party Call: While ongoing call, if user receive a new incoming call, single tap on any earbud to put the ongoing call on hold and accept the new incoming call .

### CHARGING THE CASE 3



Note: Please only use a 5V/1A adapter to charge the case as higher voltage charge the case as higher voltage
adapters can destroy the battery of the ase and earbuds.

Low Battery Indicator: When the charging case battery is low, the case ligh will start flashing quickly .

During Charging: The Flash light on the charging case

will begin to flash, this indicates that the case is charging

Fully Charged: When the case is fully charged, the LED light will steady on.

## 

Earbuds charging: Place the earbuds inside the charging case

to charge them, the flash light on earbuds will turn on , indicating

completely charged , the flash light on the earbuds will turn OFF

Earbuds completely charged: When the earbuds are

that the earbuds are charging.

Earbuds Low Battery: When the charging on earbuds is low, you will hear a low battery voice prompt and the flash light on the earbuds will flash after every 5 seconds



Step 2: Tap the sensor on either of the earbuds for 5 times to clear the pairi data , light goes off

RESETTING THE DEVICE &

Please follow the below steps when you see 2 "Wings

Phantom 500" in your Bluetooth device menu on your mobile.

or you can hear music through only 1 earbud. This means the

left and right earbuds have not auto paired with each other



Reset process is now complete and you will be able to hear music through both earbuds.

## TECHNICAL SPECIFICATIONS

etooth Version:	V5.1
ective Distance:	10m
pedance:	32Ω
duct Weight:	49g
eaker Size:	10mm
al Play Time:	About 30+ Hours
y Time In Single Charge:	About 8 Hours
k Time:	About 25 Hours
ndby Time:	About 250 Hours
se Charging Time:	1.5 Hours
buds Charging Time:	1 Hour
ed Input:	5V/1A
quency:	20Hz~20KHz
iter and Sweat Resistant:	IPX5

defect will lead to warranty being rendered null and void. Therefore, please take utmost care of your product.

\*T&C Apply

ote: Any damage to the product that is not manufacturing

SAFETY AND MAINTAINANACE 💮

Please read below suggestions in order to helping

Keep the product dry, do not put it in humid

conditions to avoid short circuit.

some plastic parts.

to clean the item

avoid loss in battery life.

prolong the product lifespan and clearly understand

Do not expose it to the peak sun or high heat for

electronic components, damage battery and deform

extended period of time as this will short lifespan of

Do not put it in cold circumstance to avoid damage

Do not use chemical products, detergent, oily liquids

On not scratch the surface with sharp items to avoid

Do not charge the case for more than 5 hours to

Avoid hearing music at maximum volume for long

periods of time as this can affect your hearing and is

Do not attempt to dismantle the product, as it

maybe unsafe especially for non-professionals.

lamaging the case and appearance.