



Introduction

Welcome to the Wings True Wireless Generation with the all new Wings Vibe. We hope you are as excited as us to feel and flaunt your latest soundwear.

But before you dive right in, we strongly recommend going through this user manual thoroughly as it contains important technical information to ensure you have a seamless audio experience with us. Once you are done reading the manual, we are sure you will be all set to.

FEEL IT! FLAUNT IT!

2

What's In The Box

2x Bluetooth Earbuds 1x User Manual
1x Portable Charging Case 1x Type-C Charging Cable
8x Ear Cushions



3

How To Pair

Step 1: Open the lid of the charging case. The earbuds will automatically power on.

Step 2: Both earbuds will auto-pair with each other and enter pairing mode.

Step 3: Turn on the Bluetooth on your mobile and pair with device name "Wings Vibe".

Step 4: Congratulations! You are now connected and can start playing media.

Note: There is no master earbud and any one earbud can be taken out first and connected with your mobile.

Single Earbud Usage

Step 1: Take out any one earbud from the charging case.

Step 2: It will automatically power on and enter pairing mode.

Step 3: Turn on the Bluetooth on your mobile and pair with device name "Wings Vibe".

Step 4: Congratulations! You are now connected and can start playing media.

Note: During mono mode usage, at any time, you can take out the other earbud also and it will autoconnect and move into dual mode.

4

Touch Controls Usage

Play/Pause: Double touch on right or left earbud to play/pause.

Changing Songs: Touch and hold right earbud for about 2 seconds to skip to next song. Touch and hold left earbud for about 2 seconds to go to previous song.

Adjusting Volume: Touch the right earbud once to increase the volume. Touch the left earbud once to decrease the volume.

Siri/Google Assistant: Triple touch on right or left earbud to activate voice assistant.

Call Controls

Answer Incoming Call: Double touch on right or left earbud to answer call.

Reject Incoming Call: Touch and hold right or left earbud for 2 seconds to reject an incoming call.

Hang Up After Call: Double touch the left or right earbud to hang up after call.

5

Charging Function

Charging the Earbuds: Place the earbuds back into the charging case. Please make sure to close the lid of the case after which earbuds will start charging.

Charging the Case: Take the Type-C charging cable. Plug in the Type-C end into the charging case and the other end into a plug point/laptop/powerbank.

Charging Level Indicators: When left and right earbuds red LED lights up it indicates under charging. When left and right earbuds red LED turns off it indicates fully charged.

The centre LED light show the case battery level as follows:

- 0-25%: 1st White LED blinking.
- 25-50%: 1st LED lights up, 2nd LED blinking.
- 50-75%: 1st and 2nd LED lights up, 3rd LED blinking.
- 75-99%: 1st, 2nd and 3rd LED lights up, 4th LED blinking.
- 100%: Fully charged, all four LEDs lights up permanently.

Note: Please do not use more than 5V output plug points to charge as it can cause damage to the case and will affect battery life.

6

Technical Specifications

Bluetooth Version: V5.0

Bluetooth Profile: HSP, HFP, A2DP, AVRCP

Frequency: 20Hz-20000Hz

Charge Jack: Type C

Charging Time: 2 hours

Music Play Time: About 6 hours

Maximum Power Transmitted: 0.01 lbs (5.0g)x 2

Output Power RMS: Total 6 mW(3mW+3mW)

Rated Input Voltage: DC 5 V, 310 mA

Frequency bands: 2.402 Ghz - 2.480 Ghz

7

Safety And Maintenance

Please read below suggestions in order to helping prolong the product lifespan and clearly understand the warranty clauses:

- Keep the product dry, do not put it in humid conditions to avoid short circuit.
- Do not expose it to the peak sun or high heat for extended period of time as this will short lifespan of electronic components, damage battery and deform some plastic parts.
- Do not put it in cold circumstance to avoid damage to PCB board.
- Do not attempt to dismantle the product, as it maybe unsafe especially for non-professionals.
- Do not use chemical products, detergent, oily liquids to clean the item.
- Do not scratch the surface with sharp items to avoid damaging the case and appearance.
- Do not charge the case for more than 5 hours to avoid loss in battery life.
- Avoid hearing music at maximum volume for long periods of time as this can affect your hearing and is not advisable.

Note: Any damage to the product that is not manufacturing defect will lead to warranty being rendered null and void. Therefore, please take utmost care of your product.

8