



USER MANUAL

INTRODUCTION

BE THE SICKEST IN THE GAME!

It's not just a tagline, it's who we are. Esports and Gaming has truly arrived in India and at Wings, we celebrate the modern Indian gamer with products that reflect the same drive and finesse that goes into the sport.

We are a community of passionate of gaming enthusiasts with the highest standards and the ambition to be the best. It is the same passion with which we add style and performance to every Wings product so you can elevate your game and enjoy the rush of that perfect headshot.

But more than anything - We are PROUD to be gamers. Just like you.

Let's Go!

·2x Bluetooth Ear buds 1x Portable Charging Case



1x User Manua 1x Warranty Card

---4x Extra Eartips(S&L)



WHAT'S IN THE BOX









2. Type-C input

3. Case lights

4. Touch sensor

5. Microphone

HOW TO PAIR 🔝

Before gueue-ing up with your squad, Pair up with us to ensure maximum victories.

Note: In case you do not connect to any device within 180

seconds of entering pairing mode, then both earbuds will

automatically turn OFF. Please put the earbuds back into the

Please make sure that the device is fully charged before using it

Step 1: Make sure your charging case is powered up. Simply open the lid of the charging case, the earbuds will turn ON

Step 2: Tap "Phantom 550" from the smartphone's Bluetooth menu. There is a voice prompt after successful connection. This indicates earbuds are successfully connected to your device.

case and repeat the process to pair.

playing media.

and will automatically enter the pairing mode.



Step 3: Congratulations! You are now connected and can start

Gaming Mode: Long press for 2 seconds on the right earbud to turn Gamina mode ON. The earbuds will do a breathing light effect .Long press for 2 sec on the right earbud again to turn Gaming Mode OFF.

TAP CONTROL USAGE

earbud to resume playing music.

earbud to activate voice assistant.

For better access and functionality during matches, use our

Play/Pause: Double Tap the sensor on any one earbud to

pause music. Double tap on any sensor again, on any one

Changing Songs: Triple Tap on the right earbud to go to

Volume. Single Tap on left earbud to decrease Volume.

Siri/Google Assistant: Long Press for 2 seconds on left

tap controls to save on those crucial moments between

Changing EQ: Tap 4 times on the touch sensor of any earbuds to switch between the EQ's.

CALL CONTROLS

Use our Cal control features to make swift decisions in game

and clutch up without breaking your focus.

Answer Incoming Call: Double Tap the sensor on any earbud to answer an incoming call.

Hang up Ongoing call: While on call, Double Tap the sensor on any earbud to hang up the call.

Reject Incoming Call: Long press the touch sensor on any earbud for 2 seconds to reject incoming call.



Our Charging Speed makes sure to leave your enemies in the dust! So Charge up and get going!!

CHARGING THE CASE 3

Note: Please only use a 5V/1A adapter to charge the case as higher voltage adapters can destroy the battery of the case and earbuds.

Charging the Case: When charging the case, the charging indicator lights on the case will do a blinking effect.

Fully Charged: When the case is completely charged, the case light will stay steady ON.

CHARGING THE EARBUDS 3

Tired from defeating your rivals? Well our earbuds need a quick break too before they are back on the field with you.

Note: Please peel off the protective film on the earbuds

charaina points before charaina the earbuds.

Earbuds Charging: When earbuds are placed inside the charging case, the lights on the earbuds will turn ON

indicating that the earbuds are being charged.

Earbuds Completely Charged: When the earbuds are completely charged, the lights on the earbuds will go OFF.

RESETTING THE DEVICE 🖅

On the rare occasion you might need to reset the earbuds. here's a guick guide after which you can get back into the

Please follow the below steps when you see 2 "Phantom 550" in your Bluetooth device menu on your mobile or you can hear music through only 1 earbud. This means the left and right earbuds have not auto paired with each other:

Step 1: Disconnect the earbuds and remove "Phantom 550" from the list of paired devices on your mobile.

Step 2: Tap the sensor on either of the earbuds for 5 times auickly to clear the pairing data, the LED on both the earbuds will turn ON and then OFF after 3 seconds.

Step 3: Put them back into the charging case, and "Phantom

550" is ready to use as it automatically turns on and pairs again.

The Reset process is now complete and you will be able to hear music through both earbuds.

TECHNICAL SPECIFICATIONS

PARAMETERS

For all the tech geeks and audiophiles, here's a full set of our specs for you to brag about with your fellow tribe.

h Version:	V5.3
Distance:	15M
ice:	32Ω
Weight:	44g
Size:	13mm
y Time:	About 45 Hours
Play Time:	About 10 Hours
e:	About 40 Hours
Time:	About 300 Hours
e Charging Time:	1.5 Hours
Charing Time:	1 Hour
put:	5V/1A
cy:	20Hz~20KHz
nd Water Resistant:	IPX5
g Port:	Туре-С

case with our earphones, so, Keep the product dry, do not put it in humid conditions to avoid a short circuit.

 We understand you carry the fire of a gamer within you, but please, Do not expose it to the peak sun or high heat for extended periods of time as this will short lifespan of electronic

SAFETY AND MAINTENANCE 🕢

Please read below suggestions in order to helping prolong the

product lifespan and clearly understand the warranty clauses:

Gamers need to hydrate after a long match. That is not the

- components, damage battery and deform some plastic parts You may be Captain Cool leader of your sauad but our products work best without a cold environment, so, Do not put
- it in cold circumstances to avoid damage to the PCB board. We know you are tech aeeks and can build your own gaming
- PC from scratch, but. Do not attempt to dismantle the product. as it may be unsafe especially for non-professionals
- Gamers are tough and our earphones are tougher, but please Do not use chemical products, detergent, oily liquids to
- dean the item. In game, the bullets and knives are the norm however.
- Do not scratch the surface with sharp items to avoid damaging the case and appearance.
- We understand your passion for power, but in this case, Less is More, so, Do not charge the product for more than 5 hours
- to avoid loss in battery life.
- Being immersed in the game is one thing, yet Avoid hearing music at maximum volume for long periods as this can affec your hearing and is not advisable.