

WINGS PHANTOM 700

TRUE WIRELESS GAMING EARBUDS



USER MANUAL



INTRODUCTION

BE THE SICKEST IN THE GAME !

It's not just a tagline, it's **who we are**. Esports and Gaming has truly arrived in India and at Wings, we celebrate the modern Indian gamer with products that reflect the same drive and finesse that goes into the sport.

We are a community of passionate of gaming enthusiasts with the highest standards and the ambition to be the best. It is the same passion with which we add style and performance to every Wings product so you can elevate your game and enjoy the rush of that perfect headshot.

But more than anything - **We are PROUD to be gamers. Just like you.**

Let's Go!

WHAT'S IN THE BOX



PRODUCT LAYOUT



1. Earbuds Lights
2. Touch Sensor
3. Microphone
4. Type-C Input
5. Case Lights
6. Charging Case

HOW TO PAIR

Before queue-ing up with your squad, **Pair up with us** to ensure maximum victories.

Please make sure that the device is fully powered before using the product.

Step 1: Make sure your charging case is charged up. Simply open the lid of the charging case and take the earbuds out from the charging case. The earbuds will turn ON and will automatically enter the pairing mode.

Step 2: Tap "Phantom 700" from the smartphone's Bluetooth menu. There is a prompt after a successful Connection. This indicates earbuds are successfully connected to your device.

Step 3: Congratulations! You are now connected and can start playing media.

Note: If you do not connect to any device within 180 seconds of entering pairing mode, then both earbuds will automatically turn OFF. Please put the earbuds back into the case and repeat the process to pair.

TAP CONTROL USAGE

Use our tap controls to save on those crucial moments between games for better access and functionality during matches.

Play/Pause: Double Tap on any one earbud's touch sensor to pause music. Double tap on any earbud's touch sensor again to resume playing music.

Changing Songs: Triple Tap on the right earbud's touch sensor to go to the next song. Triple Tap on the left earbud's touch sensor to go to the previous song.

Adjusting Volume: Single Tap on the right earbud's touch sensor to increase volume. Single Tap on the left earbud's touch sensor to decrease volume.

Voice Assistant: Long Press for 2 seconds on the left earbud's touch sensor to activate the voice assistant.

Gaming Mode: Long press for 2 seconds on the right earbud's touch sensor to turn Gaming mode ON. The earbuds will do a slow breathing light effect. Long press for two seconds on the right earbud's touch sensor again to turn Gaming Mode OFF.

Power ON/OFF: Long press for 5 seconds on any earbud's touch sensor to manually turn ON or OFF the earbuds.

CALL CONTROLS



CALL CONTROLS

Use our Call control features to make swift decisions in-game and clutch up without breaking your focus.

Answer Incoming Call: Double Tap the touch sensor on any earbud to answer the incoming call.

Hang up Ongoing call: While on call, Double Tap the touch sensor on any earbud to hang up the call.

Reject Incoming Call: Long Press the touch sensor for 2 Seconds on any one of the earbuds to reject the incoming call.

CHARGING THE CASE

Our Charging Speed makes sure to leave your enemies in the dust ! So Charge up and get going !!

Note: Please only use a 5V/1A adapter to charge the case as higher voltage adapters can destroy the battery of the case and earbuds.

Charging the Case: When charging the case, the charging case lights will blink in green colour.

Fully Charged: When the case is fully charged, the charging case lights will be steady ON in green colour.

CHARGING THE EARBUDS

Tired of defeating your rivals? Well our earbuds need a quick break too, before they are back on the field with you.

Note: Please peel off the protective film on the earbuds charging points before charging the earbuds.

Earbuds Charging: When earbuds are placed inside the Charging case, the lights on the earbuds will turn ON, and the case lights will breathe in multiple colours, indicating that the earbuds are being charged successfully.

Earbuds Completely Charged: When the earbuds are completely charged, the lights on the earbuds will go OFF.

RESETTING THE DEVICE

On the rare occasion you might need to reset the earbuds, here's a quick guide after which you can get back into the grind !

Please follow the below steps when you see two "Phantom 700" in your Bluetooth device menu on your mobile, or you can hear music through only one earbud. This means the left and right earbuds have not auto-paired with each other:

Step 1: Disconnect the earbuds and remove "Phantom 700" from your mobile list of paired devices.

Step 2: Tap the touch sensor on either of the earbuds five times quickly to clear the pairing data. The LED on the earbuds will flash.

Step 3: Put them back into the charging case and take them out from the charging case. The "Phantom 700" is ready to use as it automatically turns ON and pairs again.

The Reset process is now complete and you will be able to hear music through both earbuds.

TECHNICAL SPECIFICATIONS

| PARAMETERS | VALUES |
|----------------------------|-----------------|
| Bluetooth Version: | V5.3 |
| Effective Distance: | 10m |
| Impedance: | 32Ω |
| Product Weight: | 43g |
| Speaker Size: | 13mm |
| Total Play Time: | Upto 30 Hours |
| Earbuds Play Time: | Upto 8 Hours |
| Talk Time: | About 25 Hours |
| Standby Time: | About 200 Hours |
| Complete Charging Time: | 1.5 Hours |
| Earbuds Charging Time: | 1 Hour |
| Rated Input: | 5V/1A |
| Frequency: | 20Hz~20KHz |
| Water and Sweat Resistant: | IPX5 |
| Charging Port: | Type-C |

*T&C Apply

SAFETY AND MAINTENANCE

Please read below suggestions in order to help prolong the product lifespan and clearly understand the warranty clauses:

• Gamers need to hydrate after a long match. That is not the case with our earbuds, so, **Keep the product dry, do not put it in humid conditions to avoid a short circuit.**

• We understand you carry the fire of a gamer within you, but please, **Do not expose it to the peak sun or high heat for extended periods of time as this will shorten lifespan of electronic components, damage battery and deform some plastic parts.**

• You may be Captain Cool leader of your squad but our products work best without a cold environment, so, **Do not put it in cold circumstances to avoid damage to the PCB board.**

• We know you are tech geeks and can build your own gaming PC from scratch, but, **Do not attempt to dismantle the product, as it may be unsafe especially for non-professionals.**

• Gamers are tough and our earbuds are tougher, but please **Do not use chemical products, detergent, oily liquids to clean the item.**

• In game, the bullets and knives are the norm however, **Do not scratch the surface with sharp items to avoid damaging the case and appearance.**

• We understand your passion for power, but in this case, **Less is More, so, Do not charge the product for more than 5 hours to avoid loss in battery life.**

• Being immersed in the game is one thing, yet **Avoid hearing music at maximum volume for long periods as this can affect your hearing and is not advisable.**

Note: Any damage to the product that is not a manufacturing defect will render the warranty null and void. Therefore, please take utmost care