


# KOPFJÄGER

## REAPER GRIP W/ DIRECT MOUNT



HEAVY DUTY  
CONSTRUCTION



SMOOTH  
PAN / TILT



USER FRIENDLY  
OFFSET GRIP



LONG RANGE  
PRECISION



PROTECTIVE  
PADDING



ADJUSTABLE  
TAPERED GRIP



USER MANUAL

KJ86006

# KOPFJÄGER DIRECT MOUNT USER MANUAL

Thank you for choosing Kopfjäger, the world's best, most versatile tripod-mounted gun rest system. Every ounce of product knowledge you need to become a Kopfjäger Reaper Grip expert is contained in these few pages—the rest is just trigger time. Welcome to our ranks.

GENERAL DESCRIPTION	
Brand Name	Kopfjäger
Model Name	Reaper Grip with Direct Mount Adapter
Category Name	Gun Rests
SKU Number	KJ86006
UPC Number	81249526249
TECHNICAL SPECIFICATIONS	
Dimensions, in/mm	4.18 x 5.75 x 5.04 / 106 x 146 x 128
Vise width range, in/mm	1.57 - 2.78 / 40 - 71
Material	Aluminum
Weight, lbs/g	1.38 / 625
INCLUDED ACCESSORIES	
	Camera thread adapter

Please visit [www.kjrests.com](http://www.kjrests.com) for warranty details and informa-

## DIRECT MOUNT REAPER GRIP

The Direct Mount Reaper Grip reduces the overall size and weight of our shooting rest system and gives you the versatility to direct mount the Reaper Grip assembly to tripods with ball/leveling heads. The Direct Mount Reaper Grip fits best on tripods with a 3/8"-16 threaded screw and center column that allows rotation for horizontal panning. A 1/4"-20 adapter is provided for tripods or quick-release plates. Note: vertical movement is limited but can be achieved by loosening the tightness of the Reaper Grip.

## MOUNTING

The Kopfjäger Direct Mount Reaper Grip threads directly onto your tripod's center column with 3/8"-16 threads. For tripods with 1/4"-20 threaded studs, the Direct Mount Reaper Grip includes a thread adapter.

## SECURING A STOCK OR CHASSIS IN THE GRIP

To secure a stock or chassis in the Reaper Grip, set the stock down into the Grip just forward of your magazine well (this prevents obstructions of rifle components you may need to access). Hold the rifle so the stock or chassis is resting completely at the base of the grip. Tighten the grip knob until the rifle is secure. The Grip pivots to accommodate tapered stocks and chassis. The tops of the grips also curve inward slightly, toward the interior of the grip. The curved grip is designed to pull and hold the stock or chassis down into the bottom of the grip.

## WARNING

Before handling the Reaper Grip, read and understand the contents of your tripod manual.

- Do not exceed your tripod's maximum load capacity. (see your tripod manual.)
- Ensure the Direct Mount is fastened tightly to your tripod.
- Ensure your firearm is gripped tightly and is secured at the bottom of the grip assembly.
- Always remove your firearm and accessories from the Reaper Grip during setup and before transporting.

**NOTES:**

---

---

---

---

---

---

---

---

---

---

---