



Justice
I AM THE HEART OF JUSTICE.
LIGHT-UP
HOVERBOARD

Thank you for purchasing the Justice Light-Up Hoverboard, item AHO629JUS. Ride in style with this sleek light up hoverboard. For the best experience, please read this manual carefully and for future reference, store this manual in a safe location.

SAFETY PRECAUTIONS

1. READ ALL INSTRUCTIONS BEFORE RIDING THE HOVERBOARD
2. This product was made for kids over the age of 14. Keep out of reach from young children. Parental supervision is advised.
3. Always wear safety equipment - helmets, elbow pads, knee pads - while riding the hoverboard.
4. Always follow all local safety laws when riding the hoverboard.
5. Always ride on the sidewalk and or in a safe and clear location. Do not ride near moving vehicles, in the street, on large slopes, or uneven terrain.
6. Please recycle or dispose of the hoverboard properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of for further information.
7. Do not wear dark sunglasses, headphones or any other form of distraction while riding the hoverboard.

SPECS AND FEATURES

- Top Speed: 6 mph
- Power: 240W
- Battery: 37V, 2.0Ah Lithium Ion
- Battery Range: 5 Miles
- Weight: 14.8 lbs
- Max Rider Capacity: 175 lbs
- Solid Tire Size: 6.5 Inches
- Charge Time: 5 Hours
- Max Climbing Ability: 10°
- Front LED Lights
- Safety Shield
- Light up Wheels
- Safety Shield protection against over heating


GETTING ON

Getting on to the hoverboard may be tricky at first. Below are included tips and tricks on how to get onto the hoverboard safely. The assistance of a second person may be required to help assist the user's balance.

1. Do not turn the hoverboard on immediately. First, get comfortable standing on the platform first keeping your feet flat.

2. It is best to step onto the hoverboard quickly and without hesitation as if walking up stairs. If uncomfortable, use the assistance of a second person to safely step onto the board.

3. When turning on the hoverboard, keep in mind the sensors are sensitive to all movement.




RIDING THE HOVERBOARD

1. Press the power button to turn on the hoverboard.

2. Step onto the hoverboard platform:

- To move forward, slightly lean your body forward.
- To reverse, slightly lean your body backwards.
- To turn, look where you want to go before shifting your body and the board will follow.



3. If you need to go over bumps or rough surfaces, slightly bend your knees to absorb some of the impact.

4. To get off the hoverboard, step off the platform one foot at a time.

CHARGING

1. Using the included cable, plug one end into the hoverboard and the plug into a suitable wall outlet.
2. Make sure the charging port is dry when connecting the charging cable.
3. It will approximately take up to 5 hours for the hoverboard to be completely charged.

FCC COMPLIANCE

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

SAKAR ONE YEAR WARRANTY

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-877-397-8200 or visit our website at www.sakar.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.



©2021 Sakar International
195 Carter Drive
Edison, NJ 08817
Support: 877 397 8200
www.sakar.com