

Introduction:

Thank you for purchasing the Justice Gaming Headphones w/ Light-Up Ears & Microphone, item JUSGHS01. Now you can join video calls and play video games in style. Attach the included boom microphone to communicate with your friends. Please read this manual carefully before using your new headphones.

A Closer Look:**Contents:**


- Justice Gaming Headphones
- Boom Microphone
- User's Manual with warranty information

Features:

- Light up ears powered by a CR2032 Cell battery
- Connects to any audio device with an Auxiliary port
- Attachable boom microphone for clear communication
- Foldable cups for compact travel

Using the Headphones:

1. Plug the headphones into an audio device with an auxiliary jack/headphone jack (ie. smartphone or computer).
2. Press the power button once to turn the light-up ears On. Press it a second time and the lights will flash. Press it once more and the lights will turn Off.
3. Connect the included boom microphone into the auxiliary port for gaming and video calls.
4. For easy, compact travel, fold both sides of the headphones inward.



Replacing the Cell Battery:

The light-up ears are powered by a CR2032 cell battery. Follow the instructions below to learn how to change the battery:

1. Use a screwdriver to remove the screw on the battery compartment door.
2. Once the battery compartment is open, take out the old battery, and insert a new battery with the correct polarity (the positive + side should face up).



Positive (+) Side Faces Up

3. Once the new battery is inserted, put the cover back on the battery compartment and use your screwdriver to tighten the screw in place.

Specifications

Battery: CR2032/3V
Plug Type: 3.5mm
Cable Length: Approximately 1.5m
Rated Power: 20mw

Important Safety Precautions:

Before using the Gaming Headphones, basic safety precautions should be followed, including:

1. This product is not a toy, do not allow children to play with it. Adult supervision is advised.
2. This product should not be exposed to extreme heat or fire. Do not store in a location with temperatures above 100°F.
3. Do not crush, throw or subject this product to extreme physical force.
4. Do not use in wet or humid environments. Do not place on a wet surface.
5. Please recycle or dispose of the product properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of the product for further information.
6. Do not attempt to repair this product yourself. Contact a qualified service center if the product is in need of service.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:
Call 1-800-592-9541 or visit our website at www.vivitar.com.

To receive warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaid.

BATTERY WARNING:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickle-cadmium) batteries.
- Batteries are not to be inserted with the wrong polarity.
- Exhausted batteries are to be removed.
- The supply terminals are not to be short-circuited.

Please recycle or dispose of the battery properly. Contact local recycling facilities and/or the manufacturer of your battery for further information