





Item: JUSSP02

Introduction

Thank you for purchasing the Justice Wireless Light Up Speaker, item JUSSP02. Lightweight and portable, listen to music wherever you go using a Bluetooth compatible device. In order to get the best results, please read this manual first before using the speaker.

Important Safety Precautions

When using your Justice Wireless Light up Speaker, basic safety precautions should always be followed, including:

- 1. Do not allow children to play with this speaker without adult supervision.
- 2. Do not use the speaker near water, in wet conditions, or put on a wet surfaces.
- Do not expose the speaker to excessive heat, fire, and prolonged direct sunlight. Do not expose the speaker to temperatures above 100° F.
- 4. This product should not be handled roughly. Always press the buttons and switches carefully.
- 5. Do not use in extremely dry environments. This can lead to static discharge during usage.
- 6. Do not tamper with the electrical housing of your speaker.
- 7. Do not attempt to repair this product yourself. Contact a qualified service center if the speaker is in need of service.
- 8. Do not drop, throw, or expose your speaker to extreme physical force
- 9. This speaker is not intended for commercial use.
- 10. Do not place this product near objects that generate a strong magnetic field.
- 11. Unplug the speaker when not in use for long periods of time and during lightning storms.
- 12. Use a soft cloth to clean the speaker. Do not use any abrasive chemicals.
- 13. Please recycle or dispose of the speaker properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your speaker for further information.

Package Contents

- Justice Wireless Light Up Speaker
- USB Charging Cable
- User's Manual with Warranty Information

Specifications

Bluetooth Specification: V5.0 Bluetooth Range: Up to 30 feet Power Supply: DC 5V/1A Battery Type: 1200mAh Lithium Ion Play Time: 10 Hours**

*Applicable at 50% of maximum volume. Results will be lower when volume is higher.

BATTERY WARNING:



-The device is equipped with an integrated lithium battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.

-Do not dispose of in fire or expose to excessive heat.

Do not crush, puncture, incinerate, or short circuit external contacts.

-Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

Speaker Set-up

Charging: Using the included USB charging cable, insert the cable's micro USB end into the speaker's micro USB port. Connect the charging cable's standard USB end in a wall adapter (not included) and into a wall outlet. While charging, a charging indicator light will turn red. Once the battery has fully charged, the charging indicator light will turn off.






Bluetooth Pairing: Push the power button to turn the speaker On; the speaker will automatically go into Bluetooth pairing mode. Go into the Settings app and into the Bluetooth page on your phone. Make sure Bluetooth is turned on before connecting to the available device 'Light Up Speaker'.

Using the Speaker

- 1. Push the Power switch to turn the speaker On/Off.
- 2. Press the Play button to pause and play music.
- 3. Press the Plus button to go to the next track. Press and hold the button to increase the volume
- 4. Press the Minus button to go back to the previous track. Press and hold the button to decrease the volume.
- 5. Press the Mode button to change the mode of the speaker.
- 6. If you recieve a phone call while connected to the speaker, press the Play button to answer and end the call. to reject an incoming call, press and hold the Play button for three seconds.



Other Audio Modes:

Your speaker has a USB port and TF card slot.

Insert a drive or card into the corresponding slot to play audio.

Then, press the Mode button to put the speaker into the correct audio mode.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident

To Obtain Warranty Service and Troubleshooting Information: Call 1-800-592-9541 or visit our website at www.vivitar.com.

To receive warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANT-ABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INTO BE LIABLE FOR ANY INCIDENTAL, DIFECT, INDIPECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PROCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

