

KETTLER®

CAVALIER OUTDOOR FOOSBALL TABLE Model 7199-200

Adult Assembly Required

Made in Italy



Picture Similar

Printed on recycled paper.



Before Assembly

Before assembling or using the foosball table, please read the following instructions carefully. They contain important information for use and maintenance of the equipment as well as for your personal safety. Keep these instructions in a safe place for maintenance purposes or for ordering spare parts.

All KETTLER® products are designed in accordance with the latest safety regulations and undergo a constant process of quality control during manufacturing. The knowledge gained in this process is used to constantly improve and develop our products. In order to offer our customers the very best in product quality, we reserve the right to make technical changes at any time. In spite of this, should you have any cause for complaint, please contact KETTLER®.

Note on Safety

- The foosball table should be used only for its intended purpose, i.e. for playing with suitable balls.
- All other uses are prohibited and may be dangerous. The manufacturer cannot be held liable for damage or injury caused by improper use of the table.
- Damaged or worn components may endanger your safety or shorten the lifespan of the foosball table. Replace worn or damaged components immediately and remove the table from use until this has been done. Use only spare parts manufactured by KETTLER®.
- The foosball table complies with all safety regulations. Incorrect repairs, alterations to the design (removal of original parts, addition of other components etc.) may endanger the safety of the user.
- Instruct other persons (in particular children) using the table in its correct use, and draw their attention to any potential source of danger, especially when setting up or dismantling the table.
- Caution: During assembly, keep all items out of children's reach (choking hazard-contains small parts).
- Regularly check all screws, bolts etc. to ensure they are in good condition.
- Warning: This is a heavy product. Do not attempt to move or maneuver without adequate help and safety measures. May result in injury. Children should not move table.

Handling the Equipment


- Do not use the foosball table until it has been fully and correctly assembled and checked.
- Set the table up on a level surface.
- When not playing or storing the table, always use the included protective cover.
- Do not use corrosive or abrasive materials to clean the equipment. Ensure that such materials are not allowed to pollute the environment. In most cases a damp cloth is sufficient.
- Waste disposal: KETTLER® products are recyclable. At the end of its useful life, please dispose of correctly and safely complying with your local facilities and guidelines.
- Once the table is assembled it may not fit through your doorways. For this reason you should assemble the table where you intend to use the table. Should you wish to move the table some disassembly may be required.

Before Assembly (continued)


General Assembly Instructions

- The equipment must be assembled with care by two adults.
- Separate all the parts including the hardware. Compare quantities with the package contents section and that all items are undamaged. If there are any problems, please contact KETTLER®.
- Before assembling the equipment, study the drawings and photos carefully then assemble in the order shown.
- Please note that there is always a danger of injury when working with tools or doing manual work. Therefore, please be careful during assembly.
- Ensure that your working area is free of possible sources of danger, for example don't leave any tools lying around. Always dispose of packaging material in such a way that it may not cause any danger. There is always a risk of suffocation if children play with plastic bags!
- The fastening items required for each assembly step are shown at the beginning of the step. Use the fastening items exactly as instructed.
- Bolt all the parts together loosely at first, and check that they have been assembled correctly. Then use spanner for final tightening. Then check that all screw connections have been tightened firmly.
- For technical reasons, we reserve the right to carry out preliminary assembly work (e.g. addition of tubing plugs).
- Please keep original packaging, so that it may be used for transport at a later date, if necessary. Goods may only be returned after prior arrangement and in packaging that is safe for transportation (in the original box if possible). It is important to provide a detailed defect description/damage report.

Package Contents



Number Included-1




Number Included-2



Number Included-1



Number Included-8



Number Included-5




Number Included-2



Number Included-2

Package Contents (continued)



Number Included-8



Number Included-8
(M8 Lockwasher)



Number Included-8
(M8 Hexnut)



Number Included-8
(M8x40 Carriage Bolt)




Number Included-6
(M2.8 X 11.5 Screw)



Number Included-44
(M4 X 25 Screw)



Number Included-4
(M3.9X35 Screw)



Number Included-
10 Blue
10 Silver




Number Included-
2 Blue
2 Silver




Number Included-8




Number Included-4



Number Included-8



Number Included-
1 Set Blue
1 Set Silver



Number Included-8



Number Included-2

Assembly


Step 1




2 each required



1 required




1 required



1 required

Leg Assembly



Place legs inside cabinet at an outward angle. Horizontal bar between legs should be toward table end. (A)



Ensure holes in side of cabinet align with holes in leg. Insert two M8 x 40 Carriage Bolts from the outside in towards leg. (B)



Using hammer, lightly tap bolt heads into side (C), ensuring they are flush with cabinet (D).



Assembly

Step 1 (continued)



From inside of cabinet, place M8 Lockwashers then M8 hexnuts onto Carriage Bolt ends (E) and tighten (F).



Screw floor leveler into leg post. (G)

REPEAT STEP 1 A-G FOR EACH LEG

Assembly

Step 2

Setting the table upright

IMPORTANT: Have two people complete Step 2.



Turn the table onto its feet to prepare for the next assembly step.

Warning: This is a heavy product. Do not attempt to move or maneuver without adequate help and safety measures. May result in injury.

Step 3 Rod Assembly




2 sets required

The foosball table comes with 4 telescopic rods for each team.

The bar scheme is as follows:

- Rod with 1 blue player (Goalie)
- Rod with 2 blue players (Defense)
- Rod with 3 silver players (Forwards)
- Rod with 5 blue players (Mid-Fielders)
- Rod with 5 silver players (Mid-Fielders)
- Rod with 3 blue players (Forwards)
- Rod with 2 silver players (Defense)
- Rod with 1 silver player (Goalie)


Take special care to ensure the direction that the player faces during this assembly step.



Step 3 (continued)



Insert Blue Goalie into first rod holes at the end of table. Insert rod end without bushing by tilting rod as shown.







Ensure that player faces direction of the arrow as shown.






Insert the opposite end with bushing into rod hole lining pins with screw holes in cabinet.

REPEAT STEP 3 A-C FOR EACH ROD AS SHOWN BELOW

Use the diagram on Page 6 for additional assistance.




SKIP BALL DROP HOLE



Step 4

Rod Bushing Assembly




May be necessary to complete before proceeding with Step 4



8 required





16 required
M4 X 25



8 required



Insert the 2 part inner bushing in the open cabinet hole (which has the rod extending through) as shown. (A, B)



Ensure that it is flush with the inside of the cabinet wall. (C)



Install the outer bushing with pins on the outside of cabinet, lining it up with pins from inner bushing. (D)

Ensure that it is flush with the outside of the cabinet wall. (E)




Assembly

Step 4

Rod Bushing Assembly (Continued)



Using 2 of the M4 x 25 screws, fasten the bushing into place.




REPEAT STEP 4 A-G FOR EACH ROD

Assembly

Step 5

Rod Bearing Assembly



8 required



8 required



16 required
M4 x 25




A On the opposite cabinet hole, slide bearing over the end of rod. (A,B)



C Insert the end cap into hole. (C)

Ensure that it is flush with the cabinet's wall. (D)



E Using two M4x25 screws, fasten the end cap into place.

REPEAT STEP 5 A-E FOR EACH ROD

Assembly

Step 6 Rod Handle Assembly



8 required



Place the rod handle onto
the end of the telescopic rod.
(A)

Lightly tap handle using a
hammer until the handle end
reaches the line on the rod
closest to the table. (B)




REPEAT THE STEP 6 A-B FOR EACH ROD

Assembly

Step 7 Ball Drop Assembly



3 required
M2.8 x 11.5



1 required



Locate the ball drop assembly hole on the side of cabinet wall. It will be directly in the middle of table and will have 3 punched pilot holes surrounding it. (A)



Place ball drop into the hole. (B)
Ensure that the screw holes align with the pilot holes. (C)




Using three M2.8 x 11.5 screws, fasten the ball holder to the table. (D,E)



REPEAT STEP 7 A-E FOR THE BALL DROP ON THE OTHER SIDE OF THE TABLE


Step 8 Shroud Assembly




6 required
M4 x 25





1 required




Place the shroud over the table's edge with the rounded edge pointed away from the table as shown. (A)



Using the three M4 x 25 screws, fasten the front of shroud to table. (B)



Using three M4 x 25 screws, fasten the back of shroud to table.




**REPEAT STEP 8 A-C FOR SHROUD ON
OTHER SIDE OF TABLE**

Assembly

Step 9 Counter Assembly



2 required
M3.9 x 35




10 required



2 required



1 required



Build blue and silver counters. Separate the two blue and two silver cubes with screw holes; these need to be installed at each end of the counter rods. Place all like colored cubes on counter rod with cubes having screw holes on each end of both rods. (A, B)

Place blue counter into slot on shroud behind the blue goalie. (C)



Using two M3.9x35 screws, fasten the counter to shroud. (D)

REPEAT STEP 9 C-D FOR SILVER COUNTER.

Silver counter should be behind silver goalie.


FOOSBALL TABLE COVER



The foosball table comes with a cover included when purchased. Always cover your foosball table when not using. This protects the table from the elements and increases the life of the product to provide many years of enjoyment!



The cover is equipped with a Velcro side opening for ease of use and a tie down to ensure that the cover stays in place.



Limited Warranty

THERE ARE NO WARRANTIES, EXPRESSED OR IMPLIED, MADE BY EITHER THE DISTRIBUTOR OR THE MANUFACTURER ON KETTLER® PRODUCTS, EXCEPT THE MANUFACTURER'S LIMITED WARRANTY AGAINST DEFECTS IN MATERIAL SET OUT BELOW:

This KETTLER® Limited Warranty applies to products sold through the KETTLER® Authorized Dealer Network to the original retail purchaser and authenticated by proof of purchase from a retailer located in the United States. Any shipments made under this warranty will be shipped to the United States only. Any shipment outside of the United States will be at the sole cost of the customer. This KETTLER® Limited Warranty is a manufacturer's warranty and is not changed or modified by additional warranties extended by individual retailers at the point of sale. Manufacturer warrants this product to be free from defects in material at the time of the product's tender of delivery for a period of 3 years for residential use. This Limited Warranty is not transferable and does not cover normal wear and tear (including, but not limited to, damage and wear to tires, power shocks, drive belts and other non-durable parts). The liability of the manufacturer under this Limited Warranty shall not include any liability for direct, indirect, or consequential damages resulting from the defect. This Limited Warranty is void if the product is damaged by accident, unreasonable use, improper service, failure to follow instructions provided, modification from its original state, or other causes determined not arising out of defects in material.

This warranty gives you specific legal rights. Should this product become defective due to material within the warranty period, contact KETTLER® Parts & Service Dept. by phone at 866.804.0440, fax at 757.563.9273, or e-mail at parts@kettlerusa.com.

THIS LIMITED WARRANTY IS EXPRESSLY IN LIEU OF ANY OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND OF ANY OTHER OBLIGATIONS OR LIABILITY ON THE PART OF THE MANUFACTURER. KETTLER® NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH SUCH PRODUCTS.

Log onto www.kettlerusa.com/warranty and register your **KETTLER**[®] Cavalier Foosball Table Warranty online!

