



✂ Please register your product at
vovo-eu.com/pages/product-registration
★ to receive full warranty benefit. ★

ENGLISH
FRENCH
SPANISH
GERMAN
ITALIAN



IMUNSEN AIR PURIFIER



Imunsen Air Purifier Manual

Dear Customer

Thank you for purchasing Imunsen Air Purifier.

Please read carefully through the user manual for safe and proper use.

This manual also contains details of the warranty.

After reading through the manual, please write down the date and location of your purchase, as well as the copy of the invoice. Keep the manual in an easily accessible place.

Table of Contents

Precautions

Precautions	03
-------------	----

Product Introduction

Package Contents	04
Part Names	05

User Guide

Product Connection	06
Usage Location	08
Product Features	09
Cypress Oil Capsule Usage	15

Maintenance

Managing the product	25
Cypress Wood Filter	27
Warranty Period	28

Specifications

Product Specifications	29
FAQ	30
Warranty	32

Precautions

Precautions

Transportation

When transporting the product, please make sure the device is turned off and unplugged.

Installation

Use it after properly attaching the body's upper and bottom part. Make sure the purifier inlet surface is at least 10cm(4 inches) away from the wall.

Power Caution

Severe pressure or bending the power cord could cause damage. Do not pull the power cord with pressure when plugging. Do not use inadequate or non-certified power adaptors. Do not temporarily replace the power cord with inadequate or non-certified power adaptors.

Power Cord

User must hold the head of the power cord when connecting. When transporting or cleaning the device, please make sure to turn the power off and unplug the product beforehand.

In Usage

Immediately stop the purifier if it releases unusual odor and irregular wind, or if it behaves oddly. Do not cover the air inlet area with obstacles or finger. Please make sure to constantly open the window when used with a heating device to prevent carbon monoxide poisoning.

Regulations

Do not use the purifier in humid locations such as bathrooms.

Product Introduction

Package Contents



Air Purifier




Cypress Wood Filter



Manual, Warranty



Legs (4)



Circular Filter



EU

or

UK

Power Cord (1)




Diffuser,
Detaching Hook
(Option)

Product Introduction

Part names



Front



Top

User Guide

Product connection

1. Remove the vinyl cover from the main body.



2. Remove the filter by lifting the top part of the purifier and remove the protective cover from the filter.



3. Insert the filter into the base and attach the top part of the purifier on the base.



※ Cautions

Please make sure to line up the arrows when attaching the top part to the base.

User Guide


Product connection

4. Attach the product leg to the main body.




※ **Caution**

Please make sure to attach the first hook(1) to the main body and push the second hook(2) until you hear the clicking sound.




< Leg Structure >




< Where to Attach >

5. Remove the vinyl from the Cypress Wood Filter and assemble it to the main body.




6. Connect the power cord to a power outlet.



User Guide

Usage location




Indoor Usage

Do not place the product on uneven surfaces.

Make sure to check if the intake holes are clean and in open space.

Product features



Sleep & Eco Mode

Power saving mode is recommended to use when you go to sleep. It will reduce the fan speed when this mode is active, which is suitable when sleeping.



Turbo Mode

Quickly and efficiently purifies the air with full power of motor fan. It is most effective during cleaning, cooking, and ventilating the room. Turbo mode automatically switches to Auto mode after 3 minutes.



High Mode

Operated by selection in manual mode. High mode can give you the fresh air more quickly than low mode.



Low Mode

Normally low mode operates when the air quality is good.



Auto mode

Operates automatically depending on the air quality. Automatically change the fan speed according to the air quality, thanks to the dust sensor situated at the back of the purifier.



Power


Turning on and off the power. Press & hold the power button for 2 seconds to turn ON/OFF the device. When powered on, the device will start in the previously used mode.



Ambient light sensor (For Auto mode only)

Automatically changes mode based on the brightness of the room. Automatically operates the night mode when in dark areas, and returns to auto mode once the area brightens up.

Caractéristiques du produit



Mode Veille et Eco

Il est recommandé d'utiliser le mode économie d'énergie lorsque vous allez dormir. La vitesse du ventilateur est réduite lorsque ce mode est actif, ce qui est idéal pour le sommeil.



Mode Turbo

Purifie rapidement et efficacement l'air grâce à la puissance du moteur du ventilateur. Il est particulièrement efficace pendant le nettoyage, la cuisine et pour aérer la pièce.

Le mode Turbo passe automatiquement en mode Auto après 3 minutes.



Mode Haut

Fonctionne avec sélection en mode manuel. Le mode haut permet d'obtenir de l'air frais plus rapidement que le mode bas.



Mode Bas

Le mode bas fonctionne lorsque la qualité de l'air est bonne.



Mode Auto

Fonctionne automatiquement en fonction de la qualité de l'air. Change automatiquement la vitesse du ventilateur en fonction de la qualité de l'air, grâce au capteur de poussière situé à l'arrière du purificateur.



Marche/Arrêt

Mise en marche et arrêt de l'appareil. Appuyez sur le bouton et maintenez-le enfoncé pendant 2 secondes pour mettre l'appareil en marche ou l'arrêter. Une fois sous tension, l'appareil démarre dans le mode précédemment utilisé.



Capteur de lumière ambiante (pour le mode Auto uniquement)

Change automatiquement de mode en fonction de la luminosité de la pièce. Fait fonctionner automatiquement le mode nuit lorsqu'il se trouve dans des zones sombres, et revient en mode automatique dès que la zone s'éclaircit.

Características del producto



Modo Reposo y Eco

Se recomienda utilizar el modo de ahorro de energía cuando se vaya a dormir. Reducirá la velocidad del ventilador cuando este modo esté activo, lo que es idóneo cuando se duerme.



Modo Turbo

Purifica rápida y eficazmente el aire con toda la potencia del ventilador. Es más eficaz durante la limpieza, cocinando y cuando se ventila la habitación. El modo Turbo cambia automáticamente al modo Auto después de 3 minutos.



Nivel Alto

Funciona seleccionando el modo manual. El modo alto le puede dar el aire fresco más rápido que el modo bajo.



Nivel Bajo

Normalmente, se selecciona el nivel bajo cuando la calidad del aire es buena.



Modo Auto

Funciona automáticamente en función de la calidad del aire. Cambia automáticamente la velocidad del ventilador en función de la calidad del aire, gracias al sensor de polvo situado en la parte trasera del purificador.



Power


Mantenga pulsado el botón de encendido durante 2 segundos para encender y apagar el dispositivo. Cuando se encienda, el dispositivo se iniciará en el modo utilizado previamente.



Sensor de luz ambiente (sólo para el modo automático)

Cambia automáticamente de modo en función de la luz de la habitación. Activa automáticamente el modo nocturno cuando se encuentra en zonas sin luz, y vuelve al modo automático una vez que la zona se ilumina.

Produkt Funktionen



Schlaf & Eko Modus

Stromsparmmodus ist empfohlen beim Schlafen gehen. Es wird die Ventilatorgeschwindigkeit reduzieren, wenn dieser Modus aktiviert ist, was beim Schlafen gehen geeignet ist.



Turbo Modus

Reinigt die Luft schnell und effizient mit voller Energie des Ventilators. Es ist am effektivsten während dem Putzen, Kochen und Belüftung des Raumes. Turbo Modus schaltet automatisch auf Auto Modus nach 3 Minuten.



Stark Modus

Funktioniert nach Auswahl in manuellem Modus. Der Stark Modus kann schneller frische Luft erzeugen, als der Schwach Modus.



Schwach Modus

Schwach Modus wird prinzipiell bei guter Luftqualität eingeschaltet.



Auto Modus

Funktioniert automatisch je nach Luftqualität. Schalten Sie automatisch die Ventilatorgeschwindigkeit um je nach Luftqualität, dank des Staubsensors, der sich hinter dem Reiniger befindet.



Strom


Strom Ein- und Ausschalten. Stromknopf 2 sekundenlang gedrückt halten. Gerät Ein- und Ausschalten. Das Gerät startet mit dem vorherigen Modus wenn es eingeschalten wird.



Umgebungslichtsensor (Nur für Auto Modus)

Wählt automatisch Modus aus, je nach Helligkeit des Raumes. Schaltet automatisch auf Nacht Modus in dunklen Räumen und aktiviert Auto Modus sobald es wieder hell ist.

Caratteristiche del prodotto



Modalità Sonno & Eco

Si consiglia di utilizzare la modalità di risparmio energetico quando si va a dormire. Questa modalità ridurrà la velocità della ventola quando è attiva per permettere di dormire in ambienti silenziosi.



Modalità Turbo

Purifica l'aria in modo rapido ed efficiente con la ventola a potenza massima. È più efficace durante la pulizia di una stanza e dopo aver arieggiato gli ambienti. La modalità Turbo passa automaticamente alla modalità Automatica dopo 3 minuti



Modalità Alta

Azionata selezionandola manualmente. La modalità alta può darti aria fresca più rapidamente della modalità bassa.



Modalità Bassa

La modalità bassa funziona quando la qualità dell'aria è già buona.



Modalità Automatica

Funziona automaticamente in base alla qualità dell'aria. Cambia automaticamente la velocità della ventola in base alla qualità dell'aria grazie al sensore per le polveri situato sul retro del depuratore



Pulsante di accensione

Accende e spegne il dispositivo. Tenere premuto il pulsante di accensione per 2 secondi per ACCENDERE/SPEGNERE il dispositivo. Quando viene acceso, il dispositivo si avvierà nell'ultima modalità utilizzata in precedenza



Sensore di luce ambientale (solo per la modalità Auto)

Cambia automaticamente la modalità in base alla luminosità della stanza. Avvia automaticamente la modalità notturna quando è buio e torna alla modalità automatica quando la stanza viene illuminata.

User Guide

Product features



LED Light & LED Indicator

LED Logo can provide ambient lighting effects to the user and the LED indicator shows the air quality in 3 different colors.

● Good ● Normal ● Bad



Filter replacement indicator

The LED logo will blink for 5 seconds with a buzz when you turn on the device, indicating the filter need to be replaced.

※ Reset filter indicator

After you have replaced the filter, press & hold the power button for 3 seconds to reset the filter replacement indicator.

User Guide


ENGLISH

Cypress Oil Capsule Usage (Option)


Cypress Oil Capsule
material : 100% Pure Cypress Essential Oil
(100% Extracted from cypress wood, Chemical-free)
Country of Origin: South Korea



Please scan here to purchase the oil diffuser pod.



1. After turning off the product, use the detaching hook(accessory) to open the Cypress Wood filter.



2. Detach the product by using your finger between the hole from the capsule cover.



3. Remove the protective cover from the capsule.
※ Do not poke the cover with sharp object as it contains the Cypress oil.



- (1) Remove the protective cover.




- (2) Do not remove the transparent film.
(Otherwise Cypress oil could spill.)


Cypress Oil Capsule Usage (Option)

Cypress Oil Capsule

material : 100% Pure Cypress Essential Oil
(100% Extracted from cypress wood, Chemical-free)
Country of Origin: South Korea



4. Check the two hole to properly attach the product cover.



5. Attach the cover to the product on the one side first and then push to finish the other side.



6. Assemble the Cypress Wood filter to the main body before turning on the product.

Guide d'utilisation

FRENCH

Utilisation de la Capsule à l'huile de cyprès (en option)

Capsule à l'huile de cyprès


matière : Huile essentielle de cyprès 100% pure

(extraite à 100% à partir de bois de cyprès, sans produits chimiques)


Pays d'Origine : Corée du Sud



Veuillez numériser
ici pour acheter la
dosette de diffuseur
d'huile.



1. Après avoir éteint l'appareil, utilisez le crochet de détachement (accessoire) pour ouvrir le filtre Cypress Wood.



2. Retirez le produit en passant votre doigt dans le trou du couvercle de la capsule.



3. Retirez le couvercle de protection de la capsule.
※ Ne pas percer le couvercle avec un objet pointu car il contient de l'huile de cyprès.



- (1) Retirez le couvercle de protection.



- (2) Ne pas retirer le film transparent, (sinon l'huile de cyprès pourrait se répandre)

Guide d'utilisation

FRENCH


Utilisation de la Capsule à l'huile de cyprès (en option)

Capsule à l'huile de cyprès

matière : Huile essentielle de cyprès 100% pure

(extraite à 100% à partir de bois de cyprès, sans produits chimiques)

Pays d'Origine : Corée du Sud



4. Vérifiez les deux trous pour fixer correctement le couvercle du produit.



5. Fixez le couvercle au produit d'un côté d'abord, puis poussez pour compléter l'autre côté.



6. Fixez le filtre Cypress Wood au boîtier principal avant de mettre l'appareil en marche.

Guía del usuario

SPANISH

Uso de la cápsula de aceite de ciprés (opción)

Cápsula de aceite de ciprés



Material: Aceite esencial de ciprés puro 100 %

(100 % extraído de madera de ciprés. Sin productos químicos)

País de origen: Corea del Sur



Escanee aquí para comprar la cápsula difusora de aceite.



1. Después de apagar el producto, utilice el gancho de extracción (acesorio) para abrir el filtro de madera de ciprés.

2. Separe el producto utilizando el dedo entre el hueco de la tapa de la cápsula.

3. Retire la cubierta protectora de la cápsula.

※ No pinche la tapa con un objeto afilado ya que contiene el aceite de ciprés".



(1) Retire la cubierta protectora.




(2) No retire la película transparente, de lo contrario, el aceite de ciprés podría derramarse.

Uso de la cápsula de aceite de ciprés (opción)

Cápsula de aceite de ciprés

Material: Aceite esencial de ciprés puro 100 %
(100 % extraído de madera de ciprés. Sin productos químicos)

País de origen: Corea del Sur



4. Compruebe los dos agujeros para fijar correctamente la cubierta del producto.



5. Fije la cubierta al producto por un lado primero y luego empuje para fijar el otro lado.



6. Coloque el filtro de madera de ciprés en el dispositivo principal antes de encenderlo.

Benutzerhandbuch

GERMAN

Verwendung von Zypressenölkapseln (Option)


Zypressenöl Kapsel

Material: 100 % reines ätherisches Zypressenöl
(100 % aus Zypressenholz gewonnen, frei von Chemikalien)


Herkunftsland: Südkorea



Bitte scannen
Sie hier, um den
Öldiffusor zu kaufen.



1. Verwenden Sie nach dem Ausschalten des Produkts den Demontagehaken (Zubehör), um den Cypress Wood-Filter zu öffnen.



2. Lösen Sie das Produkt mit Ihrem Finger zwischen dem Loch von der Kapselabdeckung.



3. Entfernen Sie die Schutzabdeckung von der Kapsel.
※ Stoßen Sie nicht mit einem scharfen Gegenstand in die Abdeckung, da sie Zypressenöl enthält.



- (1) Entfernen Sie die Schutzabdeckung.




- (2) Entfernen Sie nicht die transparente Folie.
(Andernfalls könnte Zypressenöl auslaufen.)

Verwendung von Zypressenölkapseln (Option)

Zypressenöl Kapsel

Material: 100 % reines ätherisches Zypressenöl
(100 % aus Zypressenholz gewonnen, frei von Chemikalien)

Herkunftsland: Südkorea



4. Überprüfen Sie die beiden Löcher, um die Produktabdeckung richtig zu befestigen.



5. Bringen Sie die Abdeckung zuerst auf der einen Seite am Produkt an und drücken Sie dann, um die andere Seite fertigzustellen.



6. Montieren Sie den Zypressenholzfilter am Hauptkörper, bevor Sie das Produkt einschalten.

Manuale Utente

ITALIAN

Uso della Capsula di Olio di Cipresso (Opzionale)

Capsula di Olio di Cipresso


Materiale: 100% Puro Olio Essenziale di Cipresso

(100% estratto da legno di cipresso, privo di sostanze chimiche)


Paese di Origine: Corea del Sud



Per acquistare la capsula di diffusore di olio, scannerla qui.



1. Dopo aver spento il prodotto, utilizzare il gancio (accessorio) per aprire il Filtro in Legno di Cipresso



2. Utilizzando le dita, togliere il prodotto dallo scomparto sotto al coperchio della capsula.



3. Rimuovere la protezione dalla capsula.
※ Non toccare la protezione con oggetti affilati perché contiene Olio di Cipresso



(1) Rimuovere la protezione.



(2) Non rimuovere la pellicola trasparente.
(Altrimenti l'olio di cipresso potrebbe fuoriuscire)


Uso della Capsula di Olio di Cipresso (Opzionale)

Capsula di Olio di Cipresso

Materiale: 100% Puro Olio Essenziale di Cipresso

(100% estratto da legno di cipresso, privo di sostanze chimiche)

Paese di Origine: Corea del Sud



4. Controlli i due buchi per attaccare correttamente il cappuccio del prodotto.



5. Inserire prima il cappuccio sul prodotto da un lato e poi premere per finire dall' altro.



6. Riunire il filtro del legno di Cypress sul corpo principale prima di allestire il prodotto.

Maintenance

Managing the product

Cleaning the exterior

1. Use a Vacuum cleaner to remove dust from the air intake and air outlet.



Cleaning the filter

1. Remove the filter from the main body.
2. Use a Vacuum cleaner to remove larger dust from the pre-filter.



Do not use water to clean the filter.
It will decrease the filters lifespan.

Circular filter is recommended
to be replaced every year.

Cypress filter is recommended
to be replaced every two years.

Maintenance

Managing the product

Replace the HEPA filter



1. Lift the top part up.



2. Peel off the plastic bag and put it inside.



3. Match the magnet position and assemble the top part back.

Maintenance

Cypress Wood Filter



Following conditions are not defective and cannot be replaced.

- Products made from tree wood may contain knots.
- The cypress wood filter might contain scratches or dents, but is not defected as is naturally caused during production.
- The wood color or pattern may be different to the image due to the nature of wood.
- Cypress wood naturally inhales water during summer and expand, as well as naturally exert water to shrink.
Due to the above reason, the filter will naturally repeat contraction and expansion, then settle down.
- As time passes, the wood may change in size to about 5 mm, but is a natural occurrence.

- Wood may change color or shape when exposed to sunlight, thus recommended to use under shade.
- Please be cautious of usage in humid places, as the wood filter is very sensitive to humidity.
- Please do not place heavy items on top of the purifier.
- If the cypress wood filter is in contact with water, the product may contract or expand.

After a period of use, even if the scent is minimal, the effect of cypress wood remains.

Maintenance

Warranty period

Warranty

1 year from date of purchase.

Non-warranty

1. Unauthorized repairs, misuse, collisions, inadvertent misuse, liquid inflows, modifications, disassembly, use of third party components, or destruction, or alteration of labels and device number anti counterfeiting markings.
2. After the warranty time is over.
3. Damage caused by misuse.

Note : For safe transportation of the purifier, please keep its original packaging for about a month from purchase. For more detail about the warranty, please refer to page 32 of this manual.

Please register your product at www.vovoeu.com to receive full warranty benefits.

Specifications

Product specifications



Product name	M-002W / R / B , M-002DW / DR / DB (Diffuser)
Size	7.9 x 7.9 x 9.4 inches (200mm x 200mm x 240mm)
Coverage area	177sq.ft (16.5m ²)
Weight	2.2lb (1kg) Filter included
Voltage	DC 12V 2A
Power	24W
Cable	DC : 1.5m (4.9ft)
Color	White / Red / Black
Diffuser	Optional
Filter (Lifespan)	Pre-Filter+H13 True HEPA Filter+Deodorization Carbon Filter(1year)+Cypress Wood Filter
Certification	KC , ETL, FCC, CE, UKCA, RoHS, CB, PSE, GB
Country of Origin	Korea

Specifications

FAQ

Problem	Pre-check	Solutions
<ul style="list-style-type: none"> · The power does not turn on. 	<ul style="list-style-type: none"> · Did you press the power button right after connecting to the power adaptor? · Is the power plug plugged in correctly? · Is the front indicator correctly displaying? · Is the filter cover correctly assembled? · Is the Cypress Wood Filter assembled correctly? 	<ul style="list-style-type: none"> · Please allow the device some time after plugging the power to operate. · Please connect the power plug to an outlet · Please press the power button accurately to operate. · The product has a safety switch. <p>It will not turn on unless it is properly assembled.</p>
<ul style="list-style-type: none"> · There is no airflow · The airflow is weaker than first purchased. 	<ul style="list-style-type: none"> · Did you remove the vinyl from the filter when first purchased? · Is the filter properly assembled? · Is the filter contaminated? (The contamination of the filter affects the airflow) 	<ul style="list-style-type: none"> · The filter is packed in a vinyl filter when first purchased. Please make sure to remove the vinyl cover before usage. · Please make sure the filter is properly assembled. · Please clean the filter.
<ul style="list-style-type: none"> · The intake hole smells bad. 	<ul style="list-style-type: none"> · Has the product been in use where people smoke or cook food with a lot of smoke? · Was the product recently used at a different location and was relocated? 	<ul style="list-style-type: none"> · The filter absorbs the surrounding smell. Thus the smell may temporarily stay and transport with the product, but will eventually disappear. · The product may still contain smells from the previous location.
<ul style="list-style-type: none"> · What is the filter replacement period? 	<ul style="list-style-type: none"> · Hepa filter approx. 1 year, · Cypress wood filter approx. 2 years. 	<ul style="list-style-type: none"> · Please check the first day the filter was used.
<ul style="list-style-type: none"> · The Cypress Wood Filter does not have a scent anymore. 	<ul style="list-style-type: none"> · The filter may lose its scent, but the effects of the Cypress wood remains unchanged for 2 years. 	<ul style="list-style-type: none"> · If you wish to bring back the Cypress scent, please purchase the Cypress oil capsule and insert it into the purifier.
<ul style="list-style-type: none"> · Cypress Wood Filter's shape changed. 	<ul style="list-style-type: none"> · Cypress Wood Filter is humidity (water) and temperature sensitive. 	<ul style="list-style-type: none"> · Please refer to page 27 for more information.

Product specifications

Contact Us

Imunsen Customer Service Center (product inquiries, product purchase)

Hours of operation: 9:00~18:00 (excludes weekends and holidays)

Product inquiries : Support@vovoeu.com

Imunsen air purifier warranty

Model	<input type="checkbox"/> M - 002W	<input type="checkbox"/> M - 002R	<input type="checkbox"/> M - 002B
	<input type="checkbox"/> M - 002DW	<input type="checkbox"/> M - 002DR	<input type="checkbox"/> M - 002DB
Serial No.			
Date of Purchase	Year	Month	Day
Warranty Period	1 year from date of purchase		
Customer address			
Customer name			
Phone number			
Notes			

Warranty Content

1. Please contact us if you have any issues with the product or defect within the warranty period.
2. Even during the warranty period, repairs will be charged if:
 - If the customer loses the warranty.
 - If the warranty does not correctly display the purchase date, nor the copy of a invoice.
 - Damage caused by the customer.
 - Damage caused by natural disasters such as fire, gas, electricity defect, and more.
 - Damage caused by misplacement or assemble.
 - Cost for engineer visit.
 - Cartridge, filter, or accessory defect.
3. Please note that all parts removed for repair will be taken by our team.
4. This warranty will not be reissued.
Thank you for your understanding.





