



# ASTRA NEO

BOULT



Case Battery Indicator Light



Multifunctional Touch  
Indicator Light

## What's in the box ?

- Charging Case
- Earbuds
- Type C Charging Cable
- Warranty Card
- Extra Pair of Eartips

## Product specification

- Product Name – TWS Bluetooth Headset
- Model – Boult Audio AirBass
- Bluetooth Range – ~10m/33ft (without any obstacles)
- Earbuds Charging Time – 60 mins
- Frequency Range – 20Hz - 20KHz
- Technology – HFP/HSP/A2Dp/AVRCP
- Input - DC5V = 1A

## How to use your Astra Neo ?

### Touch Controls

The Touch Area (Multi-Functional Touch Panel) is located in the upper part of the earbuds handle.

### Wearing Earbuds

The earbud marked with L is worn on the left ear and the earbud marked with R is worn on the right ear

## LED Functions

### Opening the Case

Case LED indicator glows for 2s then breathes for 3s and goes off

### Closing the Case

Case LED indicator breathes for 3s then becomes steady and goes off

### Charging the Case

Front LEDs breathe continuously until charging is complete then become steady

### Case low battery (30%):

LEDs will blink thrice, take a gap of 1s and repeat this for 3 times

### When the buds are connected

**Music Mode:** Both earbuds' LEDs stay Off

**Gaming mode:** Both earbuds' LEDs will breathe

### Power ON/OFF:

#### Power ON:

**Auto:** Open the charging case and take out the earbuds to Power ON.

**Manually:** Tap and hold the multifunction button (MFB) for 3 seconds.

#### Power OFF

**Auto:** Place both the earbuds in the charging case, close the lid.

**Manually:** Hold MFB for 5 seconds.

#### Play/Pause

Tap the MFB once

#### Next Track

Double Tap the right MFB

#### Previous Track

Double Tap the left MFB

#### Volume +

Triple Tap the right MFB

#### Volume -

Triple Tap the left MFB

#### Voice Assistant

Long Press the MFB for 3s

#### Answer the Call

Tap the MFB once

#### End Call/Reject

Double Tap the MFB

#### Game/Music Mode

Tap the MFB four times

### Pairing

Open the charging case, and take out the earbuds, the earbuds LEDs will start flashing automatically until paired with a device.

Activate Bluetooth on the device, turn on Bluetooth, search for pairing name "Boult Audio Airbass" and click on it.

**Single Mode:** When on dual mode, put one earbud into the charging case. Only take one earbud out of the charging case and connect it.

### Bluetooth Lost:

Turn off mobile phone's Bluetooth, earbuds will enter pairing mode and can pair with other devices. If the connection range is exceeded, the earbuds will enter back into connection mode. If there's no connection within 5 minutes, the earbuds will turn off.

### Reset

If your earbuds fail to pair, or only one works, reset them.

1. Delete all "Boult Audio Airbass" Bluetooth records on the phone and turn off Bluetooth.
2. Put earbuds in the charging case and then take out to pairing modes, tap L&R 5 times simultaneously, hear "DU" prompt voice to clear all pairing.
3. Put earbuds back into the charging case.

### Voice Prompts

- You will hear 'power on' when the headset powers on.
- You will hear 'power off' when the headset powers off.
- You will hear 'connected' when the headset is paired.
- You will hear 'low battery' when the headset is in low power status
- You will hear 'gaming mode' when the headset is in gaming mode.

### Maintenance Instructions

Warranty is valid/invalid only basis of the below criteria:

The product should be purchased through legal and formal channels to be applicable for warranty.

Damaging the product intentionally/unintentionally, or due to natural disasters, etc. is not covered in the warranty.

**Quad Mic ENC**  
for Crystal Clear Calling



**Combat™  
Gaming**



**Mode Sync LED**



**COMBAT™  
GAMING**

