Omega

User Manual

BOULT

Know your Omega

Indicator Light   Type - C Charging Port   Multifunctional Button   Indicator Light

What's in the box ?

True wireless earbuds case
2 earbuds
Extra silicon tips
USB Charging Cable
User Manual
Warranty card

Product specification

Model Name - Omega
Bluetooth version - Bluetooth V5.2
Supported mode - HFP/HSP/A2DP/AVRCP
Sensitivity - 103 dB+3dB
Signal distance – 10m (in an ideal environment without any large obstacles)
New Weight 40.6g
Charging time - Charge the charging case for 1.5 hours, and charge the earphone for about 1 hour

How to use your Omega?

·Power On/Off
Power on: Press & hold on the left/right earbud for 2 seconds
Power off: Press & hold on the left/right earbud for 2 seconds

·Connect
The earbuds will automatically start pairing when you open the charging case, and will directly connect with your mobile phone via Bluetooth with the name "Boult Audio Omega". In case it does not connect automatically, go to your bluetooth settings, search for the device name "Boult Audio Z40" and then pair your device.

·Play/Pause Music
Tap on the MFB (multifunction button - refer to page 1) of either earbud twice.
Play previous song: Long press the MFB on the left earbud for 2 sec.
Play the next song: Long press the MFB on the right earbud for 2 sec.

·Calling
Receive/End calls: Double tap on either of the earbuds.
Reject calls: Long press on either side of the earbuds for 1 sec.

·Voice Assistance
Tap on the MFB in either earbud three times.

·Low Battery Warning
When the battery of the earbuds runs low, there'll be a beep to remind you. The earbuds will automatically turn off when they run out of power.

ANC Modes

Tap on the right earbud Active Noise Cancellation, Transparent & Normal mode.

Do's & Dont's

Do not use corrosive detergents to clean the product.

Store the product in a dry environment & charge the earbuds case at least once a month.

Please raise the volume to the appropriate level while using the product. High volume may cause a risk of hearing loss.

Do not dismantle or use the product near fire or in high-temperature environment. If expansion occurs, discontinue using the product.


Exquisite Design

Touch Control

Pro+ Calling MIC

IPX5 Water Resistant

Vicky's Choice