




BOULT AUDIO

X1-AIR USER MANUAL


For better sound quality experience, suggest use
IOS 8.0/ Android 4.3 or above operating system.

Product Introduction




Pairing Steps

Press and hold 5s



NOTE: The headset will power off automatically 3 minutes without connection.


Under power-off status, press and hold the MFB until the indicator light flashes red and blue alternatively, then the Headset enters the pairing mode;



Turn on Bluetooth on your mobile, find the Model No. of the Headset, and connect. Turn off Bluetooth of the first mobile, and repeat the step above to connect with the second mobile.

Features


Power on\off



Power on - Press and hold the multi-function button (MFB) for 2s until the BLUE light flashes.


Power off - Press and hold the MFB for 5s till the RED light on for 2s.

Call answer




Call answer - Answer by your phone or press the MFB.

Call End 




Call end - End by your phone or press the MFB;

Call Reject 




Call reject - Reject by your phone or press and hold the MFB for 2s

Last Number Redial




Last number redial - Quickly tap the MFB twice to redial the last dialed phone number.

Play Music




Play music - Press the MFB to play/pause music under music playing status;

Track Control ►►



Track control - Press and hold the "Volume +" button for 2s to skip to the next song; Press and hold the "Volume -" button for 2s to play the previous song;

Volume Adjust 🔊



Volume adjust - Press the "Volume +" or "Volume -" button to increase or decrease the volume.

Warning

- Use and keep the Headset under ambient temperatures; Don't throw it in case product damage caused.
- Don't disassemble, repair or alter the Headset.
- Don't clean the Headset with chemical solvent.
- Use a USB charger of DC5V to charge the Headset if necessary.
- Don't discard the Headset at random, or put it into fire or high temperature environment (60/140) in case of danger.