





BOULT AUDIO

PROBASS MUSEBUDS USER MANUAL

For better sound quality experience, suggest use
IOS 8.0/ Android 4.3 or above operating system.

Product Introduction




Charging the Case

- Use only 5V/1A USB charger to charge this product.
- The led light flashes green while charging, The green light keep constant on after fully charge.


Activating Earbuds and Charging Earbuds

- Put both earbuds into the charging case to activate and charge them. (pins need to be well-contacted). The LED light will turn on red while charging and it turns off when the earbuds are fully charged.



TWS Pairing and Connection with Cell Phone

Take both earbuds out of the case at the same time and they will auto power on after 2-3 seconds. Both earbuds will auto pairing, at this moment the light on one earbud flashes blue and the light on the other earbud flashes red & blue alternately. Search for "Boult Audio Musebuds" in cellphone and tap to connect both earbuds with cellphone. Please insert both earbuds into charging case and repeat above steps if earbuds fail to connect.



Wearing Earbuds




Functions

- **Power-on**

Method 1: Take out both earbuds and they will auto power on.
(LED light turn on Blue)

Method 2: Press MFB for 2s to power on (LED light turn on blue)



- **Power-off**

Press and hold MFB for 4s to power off(LED turns on red for 2s)



- **Reject Call**

Press MFB for 1s to reject incoming call.



- **Answer Call/Hang off**

Press MFB to answer incoming call and press again to hang off it.



- **Playback/ Pause**

When playing music, press MFB to pause it and press again to play it.



- **Voice Assistant**

When standby, press and hold MFB for 1s until the "beep" sound happen to activate voice assistant(Like: Siri).



- **Next Song/Previous Song**

When playing music, double press MFB on any earbud to skip track backward(previous song), double press MFB on any earbud to skip forward(next song)



Note: to be specific.

2 click R earphone= next song

2 click L earphone= before

Double Press

- **Increase/Decrease volume**

When playing music, press MFB on any earbud for 3 times to get volume down or up.



Note: to be specific.

3 click R earphone= volume up +

3 click L earphone= Volume down

Quickly press 3 times

(If Earbuds fails to connect with cellphone, no sound in left earbud or right earbud)

- Take both earbuds out of the case. Press and hold the MFBs for 5 seconds (as the below picture shows) in power off mode. Don't release your fingers until the LED light flashes red & blue alternately. When the LED light of both earbuds flashes red & blue alternately, Tap 4 times the MFB of right (R) earbud. Both earbuds will auto pairing after 3-5 seconds, at this moment the light on one earbud flashes blue and the light on the other earbud flashes red & blue alternately.
- Delete the pairing name from the pairing list in cellphone, search for "Boult Audio Musebuds" in cellphone and tap to connect both earbuds with cellphone.
- Please put both earbuds into charging case and repeat above steps if earbuds fail to connect.



When the LED light of both earbuds flashes red & blue alternately, Tap 4 times the MFB of right ® earbud.

Attentions

- If the earbuds is left unused for over two weeks, please recharge it periodically.
- Be sure to use a 5V DC,1A charger made by qualified manufacturer.
- Ensure that the distance between your device and the earbuds not too far away, Ensure that nothing is blocking the signal between your device and the earbuds.
- The implementation of the earbuds function will be different due to different protocols supported by different wireless device.
- Don't disassemble or modify your earbuds for any reason to avoid any damages and danger. Don't over charging to avoid the outbreak of a fire. Avoid exposing the earbuds to extreme temperatures(below 0°C or above 45°C). Extreme temperaturer can cause deformation of earbuds components and reduce battery life and the life span of your earbuds. Don't put the device's LED lights close to humans' or animals' eyes. Do not use the earbuds during a thunderstorm. Thunderstorms can cause serious malfunction and increase the risk of electric shock.
- Do not clean the earbuds with harsh chemicals or strong detergents.
- Please follow our company's operating instructions. If any damage or danger caused due to the improper use, the responsibility shall be undertaken by the operator.