

ASSA ABLOY is the global leader in door opening solutions, dedicated to satisfying end-user needs for security, safety and convenience



Please Note:

This document is provided as a dimensional reference and should not be printed as a drilling template unless it can be correctly scaled to 100% by your printer.

ASSA ABLOY Australia Pty Limited
235 Huntingdale Road,
Oakleigh Victoria, 3166
Australia

info.au@assaabloy.com
assaabloy.com.au

ASSA ABLOY New Zealand Ltd.
6 Armstrong Road
Albany, North Shore City, 0632
New Zealand

info.nz@assaabloy.com
assaabloy.co.nz

Door preparation template

Template

Backset 60mm

Hole positions ready for drilling Ø2mm holes x 10mm deep for face fix dummy screws.

CL

Tear along perforated line

Fold here on door edge

Tools Required

- Ø2mm Drill bit
- Power drill
- Phillips head screw driver
- Ruler or tape measure

PLEASE RECYCLE THIS PROGRAM

Door preparation and face fix installation (steps 1 - 8)

1

- DUMMY SET
- Parts and assembly. (Face fix application)

2

- Mark line on the door face approx 900mm from the floor.
- Tear along perforated line.
- Fold page along - - - dashed line and place on door edge.
- Align CL on template with marked line on door face.

3

- Drill 2x Ø2mm pilot holes 10mm deep.

4

- Partially fix screws to door face (2x revolutions).

5

- Align screw heads through large screw holes in furniture.

6

- Rotate rose furniture to align screws with countersunk holes.

7

- Lightly tighten fixing screws.
- Check lever is horizontal.
- Then fully tighten fixing screws.

8

- Pass rose trim over lever.
- Push trim to secure.

Fold here on door edge

LOCKWOOD GUARANTEE

ASSA ABLOY Australia Pty Limited ("ASSA ABLOY") warrants its Lockwood products against defects in workmanship and materials, subject to the limitations and exclusions set out in this Warranty. If, within the normal working life of a product, it is found to be defective, and none of the limitations and exclusions set out in this Warranty apply, ASSA ABLOY will supply the same or equivalent product free of charge. This is the only remedy granted by ASSA ABLOY under this Warranty. **Limitations** All electrical and electronic components used in ASSA ABLOY's Lockwood range of products (excluding batteries) are guaranteed for a period of 12 months from the date of proof of purchase, unless stated otherwise. **Exclusions** This Warranty does not cover: 1. Damage to or malfunction or failure of the Lockwood product caused or contributed to by: (a) improper installation or failure to follow fitting instructions; (b) improper maintenance; (c) fair wear and tear; (d) any modification or repair which has not been authorized by ASSA ABLOY; (e) use of substitute or replacement parts or cylinders other than genuine ASSA ABLOY parts or cylinders; or (f) use of batteries other than those specified by ASSA ABLOY. 2. The cost of: (a) removal and/or replacement of the Lockwood product; (b) freight and/or travelling time; (c) replacement batteries; or (d) any modification or repairs to a Lockwood product, unless authorised by ASSA ABLOY. 3. Damage to or deterioration of the plated finishes Florentine Bronze, Architectural Bronze, Polished Brass, Gold and Satin Brass, which are classified as soft finishes, and are subject to deterioration under some environmental conditions. 4. Damage caused by corrosion when the Lockwood product is used in a corrosive environment. 5. Personal injury, property damage or economic loss, however caused.