



1

Measure the drywall opening based on width and height.



2

You must consider the accessible opening you require to access the service area behind the panel.



Note: the accessible area for Envisivent access panels is 2" less than the required drywall opening. See table below.

3

Pick the option that best fits the accessible opening you require.

Product Code	Access Panel	Drywall Opening / Finished Size	Outer Frame Dimensions	Accessible Opening	Depth
CB5005	8" x 8" (Drywall Opening)	8" x 8"	10.125" x 10.125"	6" x 6"	0.487"
CB5006	10" x 10" (Drywall Opening)	10" x 10"	12.125" x 12.125"	8" x 8"	0.494"
CB5007	12" x 12" (Drywall Opening)	12" x 12"	14.25" x 14.25"	10" x 10"	0.494"

CB5006: Envisivent Magnetic Flush Mount Access Panel 10" x 10" Drywall Opening

