


AIR SUPPLY SIZING GUIDE

www.envisivent.com



Measure your duct opening based on its width (longer side) and height (shorter side).







Refer to the Product Sizing Chart below to identify which Air Supply Vent fits most closely to your sizing requirements.

Note: If your boot duct comes out to the face of the drywall, you may have to cut back the metal a 1/2 " to allow enough depth for the vent to fit flush against the drywall. If the duct cannot be modified, please contact us to discuss custom options.

Product Code	Air Supply Vent (Duct Opening)	Drywall Opening / Finished Size	Slotted Area	Outer Frame Dimensions	Depth
CB5002	10" x 4" (Duct Opening)	11" x 5"	9" x 3"	13.5" x 7.5"	0.494"
CB5023	10" x 6" (Duct Opening)	11" x 7"	9" x 5"	13.5" x 9.5"	0.494"
CB5024	12" x 4" (Duct Opening)	13" x 5"	11" x 3"	15.5" x 7.5"	0.494"
CB5070	4" Round Vent	10" x 10"	4" d	N/A	0.545"
CB5071	5" Round Vent	10" x 10"	5" d	N/A	0.545"
CB5072	6" Round Vent	10" x 10"	6" d	N/A	0.545"

IMPORTANT: YOU MUST CONSIDER THE DRYWALL OPENING REQUIRED FOR THE AIR SUPPLY VENT YOU HAVE CHOSEN BASED ON OUR DUCT OPENING DIMENSIONS.

CB5002: Envisivent Removable Flush Mount Ceiling/Wall Air Supply 10" x 4" Duct Opening

