



Z E G A

INTELLIGENT
COOKWARE




Welcome to Zega
User guide

What's included




Zega 5.0L / 5.2qt. pot



steamer / grater



Analogue SmartControl
Knob



elevated meat rack

Connect with Zega App

1. Download and install app



Scan QR code or
search for "Zega
Intelligent Cookware"



Download on the
App Store



GET IT ON
Google Play

2. Create Zega account

To create your Zega account, swipe through the welcome screens and select Sign up. Enter your name, email address and password (min 8 characters) and press Sign up to be taken to the Main Menu.

3. Add Zega Analogue to the App

In the Zega App, go to Settings > Manage Devices and press + to add a new device.

The on-screen instructions will guide you through the process, selecting Zega Analogue from the list. Once paired you are now ready to start using Zega.

Cook with Zega

Cook using Recipes

Selecting Recipes allows you to choose one of the delicious and healthy recipes created for you by our expert chefs.

Each recipe has a list of ingredients and easy instructions for you to follow. Simply prepare the ingredients, add them to the pot and follow the instructions to guide you through the cooking process.

When your Zega has reached the required temperature, switch off the stove and select Start Cooking.

Cook using Quick Cook

Selecting Quick Cook allows you to use or create your own recipes from scratch. This gives you all the functionality of Zega while allowing you to unleash your creativity.

Analogue SmartControl

The Analogue SmartControl knob contains a built in thermometer. Once you've put the ingredients in the pot, heat it up until the thermometer's needle reaches the red zone. Then switch off the stove and the self-cooking phase will begin.



With the handy countdown timer on the Zega App, you'll always know how long to go and at what time your food will be ready to eat. During this self-cooking process, you can continue to browse the app by pressing the cross and clicking browse.

Care & Maintenance

Cleaning

While the Zega pot is dishwasher-safe, the lid and analogue SmartControl knob is not, and must be washed by hand using warm soapy water and ensure it dries thoroughly before storage.

Storage

All of the accessories fit inside the Zega pot for storage.

Safety

Important safety instructions

- 1 Read all instructions
- 2 Never touch hot surfaces
- 3 Close supervision is necessary when appliance is used by or near children
- 4 Do not operate the appliance if it has malfunctioned or been damaged in any manner
- 5 Do not use outdoors
- 6 Do not place the device in a heated oven
- 7 Use extreme caution when moving the Zega pot when containing hot liquids
- 8 Do not use Zega for anything other than its intended use
- 9 Do not remove the SmartControl lid during cooking as it prevents the SmartControl knob from functioning correctly
- 10 Do not remove the SmartControl knob whilst the Zega pot is on the heat
- 11 Always protect surfaces when removing the pan from the heat whilst self-cooking mode.
- 12 Never allow Zega to boil dry.

Warranty & Contact

Lifetime guarantee

Your Zega comes with a lifetime guarantee. If you run into any issues, please contact support@zegacookware.com with the receipt, a detailed description of the issue with photo/video evidence, if possible.

The lifetime guarantee excludes damage resulting from (i) normal wear and tear, accident, misuse, abuse or commercial use, (ii) scratches, stains, discolouration, corrosion or damage from overheating, to the interior or exterior of the pan. A slight yellowing of the surface can occasionally happen after heating. This is normal and completely harmless and doesn't affect the performance of the pan and is therefore excluded from the warranty.

Get in Touch

If there is something that we have not covered above, please get in touch with us at:
support@zegacookware.com