

## USER GUIDE

Thank you for choosing **Adelaide Party & Wedding Hire** for your event needs! Using our **Popcorn Machine** is a breeze. Here's a step-by-step guide to get your party poppin:

- 1 Begin by carefully inspecting all the items to ensure everything is included:  
**Popcorn Machine + Power Cable + Kernels Kits + Popcorn Bags**
- 2 Plug in the power cord and turn all switchers to the "on" position.
- 3 Preheat the kettle for approximately 2-4 minutes (first batch only).
- 4 Cut the top off one Kernels Kit and add all ingredients to the kettle; then close the lid and the door.
- 5 Wait for the popcorn to start popping. The process usually takes 2-4 minutes. Dump the popped corn from the kettle by turning it when the popping stops.
- 6 For additional batches repeat steps 4 and 5.
- 7 After the last batch, turn both the kettle switch and the stirrer motor switch to the "off" position.

## CLEANING INSTRUCTIONS

- 1 Unplug the Popcorn Machine from power.
- 2 Use the built-in tray to collect and dispose of the unpopped kernels.
- 3 Use a non abrasive damp cloth to clean the inside and outside of the Popcorn Machine, including the kettle.