RUNHOOD

PORTABLE POWER STATION

appliances at the same time.

power left for the car's battery.

13. DO NOT place heavy objects on the device.

10. When charging, DO NOT remove the EB324 from HE600-U.

18. Please go to RUNHOOD'S USER MANUAL for more information.

charge and discharge once every three months.

When recharging with adaptor and USB-C simonteniously, please do not charge any other

12. Charge the battery to a minimum of 60% of its full capacity before storing it. It is recommended to

15. If the product is submerged in water during use, remove the product immediately and leave it in a

17. When recharged through the car, please keep car's engine working or make sure there is enough

14. Recycle and dispose of RUNHOOD Power Station in accordance with the local regulations.

safe and open area. The battery should not be used again under any circumstance. 16. If the product catches fire, it is recommended to use fire extinguishing equipment in the following

order: water, sand, fire blanket, dry powder, carbon dioxide fire extinguisher.

- 1. Single module DOES NOT have any function unless combined with necessary modules.
- 2. Clean outlets and surfaces to avoid abrasion, energy loss and charging failures.
- 3. Only use RUNHOOD batteries with this product, RUNHOOD takes no responsibility for any damage caused by non-RUNHOOD Power Station batteries.
- 4. Children and those with impairments should operate the device with assistance.
- 5. Don't use the product in a strong electrostatic or electromagnetic environment which may cause the battery control board to malfunction and cause serious hazard during use.
- 6. DO NOT insert pins, wires, or other metals into the device case, outlets, or controls. Doing this may short circuit the product.
- 7. DO NOT puncture or incinerate the product or the accessories.
- 8. Keep RUNHOOD Power Station dry and do not expose to high heat or water.
- 9. The discharging temperature of Energy Bar 324 is -68~113°F/-20~45°C, while the charging temperature is 32~104°F/0~40°C.

◆ MODULES



LED FLASHLIGHT MASTER POWER ON/OFF DC INPUT: ADAPTER/CAR CHARGER/ SOLAR CHARGER

PD 100W INPUT/OUTPUT

© USB-C PD 100W INPUT/O

© CAR PORT

® USB-A QC3.0 * 2

© DC OUTPUT * 2

© USB-C PD 100W OUTPUT 1 110V AC OUTLET *


(12) LCD DISPLAY



AC ENGINE 80 (AE80-U)

USB-C PD 100W INPUT/OUTPUT 2 USB-A FAST CHARGE OUTPUT 28W * 2 3 USB-C PD 100W OUTPUT

USB ENGINE 256 (UE256)



ENERGY BAR 324 (EB324)

ADAPTER VARIES IN DIFFERENT COUNTRIES

HOST ENGINE 600 (HE600-U)

ACCESSORIES







CAR CHARGER 12V 10A 120W max



DC Y CABLE DC6530 port



SOLAR CHAGRING CABLE (6530)



SERI 100W 15V-23V



POWER STATION of 648Wh, 600W

This combination (HE600-U * 1 + EB324 * 2) is with design of swappable battery providing virtually unlimited durability. With an extra pair of EB324s, it can easily reach the capacity of 1296Wh.

MINI POWER STATION of 324Wh, 80W

This combination (AE80-U*1 + EB324 * 1) provides an AC output of 80W (230V,50Hz), which can provide AC power to any appliances with rated power of 80W or less.



This combination (UE256 * 1 + EB324 * 1) is with 2 outputs (USB-C, PD 100W) and 2 outputs (USB-A, QC3.0 28W), which has a maximum total power output of 256W. It can charge smart phones, laptops, tablets and other devices that can be recharged


through the USB port.

◆ RECHARGE METHODS

IMPORTANT NOTICE: The rechargeable module is EB324. Other modules are only application interfaces, but not a storage of energy. There are two ways to recharge the EB324: one with HE600-Uand the other with UE256. You need to combine the EB324 with HE600 or UE256 for recharging the EB324. We highly recommend to recharge your EB324 in pairs.



- 1. Insert two EB324s into HE600-U
- 2. Connect the Adapter/Car Charger/Solar Panel to the DC input on HE600-U
- 3. FAST RECHARGE: USB-C PD 100W input can work simultaneously with DC input to recharge the EB324 faster. When recharging with adaptor and USB-C simonteniously, please do not charge any other appliances at the same time.
- 4. When charging, DO NOT remove the EB324 from HE600-U
- 5. The AC and DC output can work normally when only using one input for recharging. DO NOT using any AC or DC output when FAST RECHARGING.



RECHARGING EB324 THROUGH UE256

- 1. Connect EB324 with UE256.
- 2. Connect the recharge cable to the USB-C PD 100W IN/OUT port to recharge.
- 3. When charging, DO NOT remove the EB324 from UE256.
- 4. The USB-C recharge cable and adapter is not included in our product range. Users can purchase the cable and adapter at their own preference from the market



MULTY SOLAR PANEL CONNECTION

- 1. The DC input of HE600-Ucan reach 200W max. You can use a maximum of two RUNHOOD Solar Panels to recharge.
- 2. Use the DC Y cable to connect two solar panels in a parallel connection.
- 3. To recharge with HE600-Uand UE256, please refer to the recharge methods instruction in RUNHOOD's USER MANUAL