


Positioning headset:

Over Ear Placement





Around Neck Placement



Adjust Air Flow


- 1 Move the arm in an up/down direction to adjust the oxygen inlet.



This hole should face towards user's direction of breathing.

Positioning headset:

Over Ear Placement





Around Neck Placement



Adjust Air Flow


- 1 Move the arm in an up/down direction to adjust the oxygen inlet.



This hole should face towards user's direction of breathing.

Positioning headset:

Over Ear Placement





Around Neck Placement



Adjust Air Flow


- 1 Move the arm in an up/down direction to adjust the oxygen inlet.



This hole should face towards user's direction of breathing.

Positioning headset:

Over Ear Placement





Around Neck Placement



Adjust Air Flow

- 1 Move the arm in an up/down direction to adjust the oxygen inlet.



This hole should face towards user's direction of breathing.