




① Run the program




② A [data] folder will automatically be generated

③ Enter the [/data/drivers] folder





④ Run CH341SER.EXE to install the driver

Install the driver



Click Install and wait for the driver to finish installing



- ① Connect the clock to the computer using the data cable from the packaging box
- ② Run EleksTube.exe



- ③ Connected status turns green and shows the device number and firmware version, indicating successful connection. Otherwise, unplug and replug the device and restart the software to retry.

Double-click to replace picture

Or click "Batch Change Picture" to select images.

Switch Dial Style

Photo mode


Backlight Switch

12/24 hours


Sync PC time

Connection Status

Sleep mode



After selecting the pictures, click on "Upload"




Input the name and password of the 2.4G frequency Wi-Fi

Select your time zone



Click the "UPDATE" button to select firmware update



Select the desired dial style and upload it to the clock