


# ROLLOVA | 正面

- OLEDスクリーン
- 現在の測定単位
- ズレモード指示ランプ(左右各一個あり
- ・開始/停止測定指示ランプ

# ROLLOVA | 裏面

- ・ゴムローラー
- •メインボタシ-
- 補助ボタン(ズレモードとメニュー設定) クリックで「ズレモード」に、クリックすると 半径を足す。ダブルクリックすると直径を 足す。





- 裏面のメインボタンをクリックし / て瀬品を呼覚ます
  - メインボタンをずっと押すと
- 正面底部の指示ランプを点灯してから転がって測定する。
  - メインボタンを外して測定停止
- メインボタンを再クリックしてメ モリ保存モードに入る
- ローラーを転がって「是」「否」で 保存するかを選びます。



- 裏面のメインボタンをクリックして製品 を呼覚ます
- •補助ボタンをずっと押して設置画面に入る
- ・ローラーを転がってメインボタンで設置 項目を設置する。

『CM』センチメートルモード 『INCH. x』インチコンマモード

- 『INCH1/n』インチコンマモート
- 『DATA』メモリDATA訪問モード
- 『ADJUST』測定精度を調整



# **BEDAIB** COIDELINE

### 

。专押予-バイヘリシ手両、ブノ回ご角裏をAVOLLOYA・

。るも連回JIC回信制で群勝の手両。

式tlthC類O一次式此雷、對下宗戟交此雷· 

。いちお〉意封 こまろこいなれるりかりなべし向えで一封向


図此事I:I

必要:2個CR1632ポタンリチウム電池

## ROLLOVA 製品修理

。いちがく路重ごJmoo.lismg@ngisəbozodlɔt:スノイベルー×千雷。をまし い頭は銘重〉な園園ご、それしまであた路間ので同い中用あごをAVOLLONも対象ないよ

!をまし式い妖猟〉をいいな向い題問るを関AVOJJOR




Please replace and dispose the batteries according to local tegulations. They should not be treated as may household waste, Improper disposal of batteries may lead to environmental pollution.

please use other measuring tools to proofread the values. POLLOY AND Subtitles and logos are registe Product Statement:

ROLLOVA electronic
tool; the measured length data is only providing a
reference for your work, the measurement of length
value is noty protected by law. In the case of accuracy,
be and proper or management of the properties of the

form of commitment. rights reserved, this manual does not constitute any POLLOVA, HOZO subtities and logos are registered trademarks owned by HOZO Dailova. Electronic rulers are parented trademarks owned by the laws appearance and functions are protected by the laws appearance and fund are protected by the laws are protected by the United State and china. Hotsoed cost Most Design and rights reserved, this manual does not constitute any cidnts reserved.



This product should not use incompatible batterfies and external power; this product is non-rechargeable, these actions may cause product a non-rechargeable, explosion or other hazards.

This product can only be used with accessories and replace parts with third-party accessories, this product and principarty accessories, this action may break the warranty for this product. If the amperature is too high or too low, it may benefit the snape of 0. and 35. C. If the amperature is in the arrange of 0. and 35. C. If the amperature is in the arrange of 0. and 35. C. If the broadent with the product or one of the components in the product or too not but this product in water or use in extremely humid conditions. This action may damage the internal circuit board of the product.

