Electric Scooter S6

**User Manual** 

Contents

1.Safety instructions

1.Safety instructions4	You are responsible for ensuring the safety of new riders. Please assist him/her to learn to use this product until he/she learns the basic operation of this scooter.
2. Packing list6	Please ensure that each new rider wears a helmet and other protective gear.  4. Follow the tips and warnings in this manual can reduce risks, but it cannot eliminate all risks. Please keep in mind that when you use a scooter, you may be at risk of injury or death due to loss of control, collision, and falls. The scooter is
3. Product function diagram7	only suitable for thehard pavement above, it is recommended to use it in a relatively closed pavement environment (such as inside the community, parks, special venues, etc.) Do not pass through places with obstacles and
4. Charging9	contacts. When entering an unfamiliar environment, be vigilant and slow down.  5. In order to reduce the risk of injury, you must read and follow all "Caution" and "Warning" notices in this manual. Please do not over speed and
5. Folding and carrying10	do not on the motorway. 6. For the first riding, please do not choose areas where children, pedestrians, pets, vehicles, bicycles or other obstacles and potential hazards
6. Maintenance11	may appear. 7. Please respect the rights of pedestrians when riding. Avoid frightening pedestrians, especially the elderly, children, the disabled and pregnant women. When approaching pedestrians from the rear, remind pedestrians and
7. Specification12	slow down when passing. Please abide by local traffic laws and regulations.  8. When riding in countries and regions where there are no laws and regulations related to electric scooters, you must strictly abide by the safety
8. Trademarks and legal notices13	requirements for cyclists in this manual. Engwe will not assume any responsibility for any property loss, personal injury, accident or legal disputes caused by the use behavior that violates the safety tips in this manual.  9. Before riding the scooter, please check and make sure there are no loose
9. Warranty14	fasteners and damaged parts. If the scooter makes abnormal noise or alarm sound, please stop using it immediately and consult with your purchasing point or email to the manufacturer.
I	10. Please observe the read surface when riding, avoid obstacles and

less than 120kg. Please comply with the following safety tips: 1. The electric scooter S6 is a product designed for personal urban A. Those who are not suitable for riding this scooter include: transportation, which has the property of a means of transportation, and the safety risks which all means of transportation may have.

ii. People unable to engage in vigorous physical activities due to illness. i. People who have trouble maintaining balance

2. The Kick Scooter is a recreational product. Before mastering riding skills, you need to practice. Engwe is not responsible for any injuries or damage caused v.People whose weight exceeds the prescribed limit (please refer to the by a rider's inexperience or failure to follow the instructions in this document. instruction manual" Specification"). v.Pregnant woman. 3. Before lending your scooter to someone else, make sure that they have B.Children need to ride scooters under adult supervision. read this manual, watched the instructional video, and earned novice instruction. C.Please abide by the local laws and regulations while riding. Do not ride

4. Follow the tips and warnings in this manual can reduce risks, but it cannot E.The Scooter is not designed to ride when it is snowing, raining, slippery, muddy eliminate all risks. Please keep in mind that when you use a scooter, you may be or icv. Do not ride a scooter across obstacles(sand, stones or roadblocks), which at risk of injury or death due to loss of control, collision, and falls. The scooter is may cause a loss of balance or grip, and result in a fall. nly suitable for thehard pavement above, it is recommended to use it in a F.Damages and losses due to water ingress are not covered by the warranty elatively closed pavement environment (such as inside the community, G.Please avoid riding at night. parks, special venues, etc.) Do not pass through places with obstacles and H.Please do not suddenly accelerate or decelerate. Please do not drive at a contacts. When entering an unfamiliar environment, be vigilant and slow down speed exceeding the limit of the scooter, otherwise there may be a risk of 5. In order to reduce the risk of injury, you must read and follow

6. For the first riding, please do not choose areas where children 13. Make sure to use the original chargers from Engwe to charge the pedestrians, pets, vehicles, bicycles or other obstacles and potential hazards 14. Only use parts and accessories approved by Engwe. And do not modify

> your scooter. Modifications to the scooter may affect the operation of the scooter, 7. Please respect the rights of pedestrians when riding. Avoid frightening resulting in serious injury damage and invalid warranty. 15. Children should not use scooters or play with scooter parts. When riding, the scooter body vibration will cause the driver's body

charger or power outlet is wet.

scooters in areas prohibited by the local law.

11. This product is suitable for users aged 14-60 years old and weighing

D. For a safe ride, you must ensure that you can see the area in front, and you

12. Please do not try to charge your scooter when the charging port,

regulations related to electric scooters, you must strictly abide by the safety 16. It is recommended to park on a flat and solid ground. If parking on a requirements for cyclists in this manual. Engwe will not assume any slope, the kick stand must face downhill to prevent overturning. Do not allow the responsibility for any property loss, personal injury, accident or legal disputes scooter head to rush down to prevent the kick-stand support from closing under

9. Before riding the scooter, please check and make sure there are no loose check whether the scooter body is stable and prevent the scooter(from sliding fasteners and damaged parts. If the scooter makes abnormal noise or alarm wind or shaking) from tipping over. Do not park in busy areas. It is recommend

10. Please observe the road surface when riding, avoid obstacles and smooth ground (including but not limited to wet ground, loose sand, stone ground and surface, etc).

caused by the use behavior that violates the safety tips in this manual. gravity and the vehicle toppling over. After putting down the kick-stand, please

sound, please stop using it immediately and consult with your purchasing point or to park near the wall. Please park the scooter on a flat 17. In order to get a better driving experience, it is recommended to

> maintain the product regularly. 18. Please read the user manual before charging

19. Do not touch the brake parts of the scooter,, injury may occur.

Assembled KickScooter

Please carefully check whether the items in the packing box are complete an


intact. If there is any part missing or damaged, please contact your point of

Please retain the box and packaging materials at least 15 days in case you

purchase or email to manufacturer

need to ship your Kick Scooter in the future.

2. Packing list



3. Product function diagram

## Turn signal buttons

Speed Mode Power display: a total of five cells, each cell represents about 20% power When the grid flashes, it means the power is very low at this time, please Fault display: Error indicates that a fault occurs, and the instrument displays the fault code. In this case, please contact the after-sales service for repa Error=5

Dashboard & power switch

scooter fails, the dashboard displays the fault code.

Error=9

inserting the key into the keyhole.

Power switch: To turn on the power of the vehicle, turn the key to the right afte

Dashboard: Displays the current driving speed of the E-scooter. When the

# Speed mode: Three modes, the maximum speed is shown in the table below.

charge or continue to use the battery!
Close the charge port cover when not charging. \_\_\_\_\_ (Charging port)

The Improper disposal to used batteries may seriously pollute the environment. Please comply with the local regulations when disposing of the battery. Do not discard this battery as one desires. The battery in good condition can maintain a good operating state even afte driving for many miles. Please re-charge the battery on time, to avoid the battery is completely draining. At the indoor temperature 22°C, the battery has the best battery life and performance. While at the temperatures under O°C, the battery life and performance may degrade Generally, the range of the same battery at-20°C is only half of 22°C.W the temperature rises, the range will recover. Typically, a fully charged battery should retain power for 120- 180 days. A low-power battery should retain power for 30-60 days. Remember to charge the battery after each use. Completely draining the battery may cause permanent damage to the battery. Electronics

5. Folding and carrying

scrubbed with a toothbrush and toothpaste, then cleaned with a soft, wet cloth. Do not use alcohol, gasoline, kerosene, or other corrosive, volatile solvents to clean your scooter. These substances may damage the appearance and internal structure of the body of scooter. It is forbidden to spray the scooter with a pressure water-gun or water pipe. Before cleaning, make sure the scooter is powered off, and the charging cable has been unplugged and the rubber cover o the charging port has been fastened. Otherwise it may cause damage to electronic components or the battery. When the scooter is not in use, please place it in a bright and dry place. Do not park the scooter outdoors. Sun exposure or extreme temperature conditions(overheating and too cold) will accelerate the aging of plastic parts For age of and may lead to a reduction in battery life. Battery dis-assembly and maintenance Max. of slope Do not use batteries made by 3rd parties without authorization, otherwise Working temperature there may be safety risks. Do not store or charge the battery at temperatures outside the stated limits (see Specifications) Do not touch the battery contacts, and do not dis-assemble or pierce the case of the battery. Avoid the short circuit caused by metal objects touching the battery contacts, otherwise it may cause battery damage or even personal injur t is forbidden to put the battery into fire, otherwise it may cause the battery Rating voltage fail, overheat, or even risk of fire. Do not charge or use your battery if it is damaged or seeing trace of water. Please do not try to dis-assemble the battery, otherwise there is a risk of fire. Users are not allowed to repair the parts contained in this scooter by themselves, without authorization. Do not ride the scooter at temperatures outside the stated limits (see Specifications), because the power of the motor will be limited, which may cause

inside the battery record the charge-discharge condition of the battery; damage

caused by over-charging or under-charging will not be covered by the Limite

Use a soft, wet cloth to wipe the mainframe clean. Dirt hard to remove can b

7. Specification

The more familiar you are with scooter, the more safety you will get on riding 1. Read this user manual carefully before riding.

the actual product.

8. Trademarks and legal notices

2. Do not allow other people to ride this scooter before they read this manual

All rights reserved by ENGWE Technologies Co., Ltd.

Manufacturer: ENGWE Technologies Co., Ltd.

ENGWE is a registered trademark of ENGWE Technologies Co.,

trademarks mentioned in this article belong to their owners.

Ltd.; Android is a trademark of Google; App Store is a sign of Apple service; other

and instructions as possible. However, due to the continuous improvement of

product functions and design changes, it may still be inconsistent with the

product you purchased. Respect. Due to product updates, the actual product n

deviate with the color and appearance mentioned in this manual. Please refer to

When printing this manual, it has included as many function introduc-tions

3. Please read this manual carefully. All the components of the scooter mus be correctly installed according to the instructions, meanwhile, make sure the

installation is not too loose or too tight, to avoid damage or failure. 4. To minimize the risk, please purchase insurance in time after purchasing

5. Before riding, please check the installation status, wheel performance and battery status according to the instructions in the manual. Mark sure the scooter is a proper status, no signs of loosening or damage on any parts. If ther

are any signs of abnormality, please stop riding it immediately and contact t after-sales for checking and guidance. 6. You are obliged to know all relevant laws, regulations and policies

regarding riding scooters in your area, and strictly comply with applicable law regulations and policies.

7. The data and parameters of the scooter will be varied with different

models. It may be subject to change without notice.

8. To the extent permitted by the law, ENGWE reserves the right to interpre and explain this statement. This statement is applied by the laws of the People's

·Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference,

9. Warranty

and (2) this device must accept any interference received, including interference equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in

20cm between the radiator & your body.

Republic of China. ENGWE will not be liable for compensation for the cause of reimbursing the misuse of the product. With compensation, liability and loss,

ENGWE will not be liable for compensation. Riders shall bear their own responsibility for unforeseen or occurring risks encountered on riding.

Thank you again for your choice and trust in ENGWE.

conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance

· Reorient or relocate the receiving antenna.

Thank you for purchasing ENGWE products. Please consult the warranty

This equipment has been tested and found to comply with the limits for a

radiate radio frequency energy and, if not installed and used in accordance

with the instructions, may cause harmful interference to radio communica-tions

installation. If this equipment does cause harmful interference to radio or

on, the user is encouraged to try to correct the interference by one or more of the

·Connect the equipment into an outlet on a circuit different from that to which

television reception, which can be determined by turning the equipment off and

However, there is no guarantee that interference will not occur in a particular

· Increase the separation between the equipment and receiver.

Class B digital device, pursuant to part 15 of the FCC Rules. These limits are

designed to provide reasonable protection against harmful interference in a

installation. This equipment generates, uses and can

policy with your purchasing point. In case of any assistance needed, please

## 7. Specification.....