


Guide Secuyou Smart Lock iPhone & Apple Watch



Frontpage (Lock)

support/FAQ


shop

press anywhere to admin (see page 2)

lock and unlock

works only for Locks Model Access / Model Security can be upgraded, see shop

all locks, swipe



delete, swipe left


press + to add lock. press the black bar. choose you code.

remember to press the UNLOCK Button to wake up the lock before adding the lock.



Overview (Locks)

Guide Secuyou Smart Lock iPhone & Apple Watch



Admin lock


firmware update

change name /
press safe

If Home Lock is ON the lock will stay in the selected lock position when the smartphone is disconnected (no autolock)

Handle sensor normally has to be on. Off is just in case the zero point of the handle is bad, old doors. Then the motor is running no matter status of handle position when lock/unlock is needed.

send data to our support team here, remember to email on info@secuyou.dk with name of the door



Shop

purchase / to upgrade Model Security to Model Access.
And iPhone watch

Guide Secuyou Smart Lock iPhone & Apple Watch



- 1) install lock in app on smartphone
- 2) lock is stored in iCloud (happens automatically)
- 3) watch get access to lock in iCloud (happens automatically)
- 4) press SCAN to get connection between watch and lock

Now you can see the status of the lock. And if you buy access (by shop in phone app, see page 2), you can control the lock directly from the watch.

Remember to turn on iCloud under Apps that use iCloud for both the Secuyou App and the Watch.