

# Identifying parts for MAJESTIC Model

HEAD REST

HEAD REST  
CUSHION  
WITH MASSAGE

INFINITY  
OVERFLOW

ADJUSTABLE  
FOOT RESTS

HOT/COLD  
WATER  
VALVE

AIRJET  
SWITCH

EASYDRAIN  
PULL  
HANDLE

ADJUSTABLE  
BACKREST

ARMREST

CONTEGO  
JET-LINER  
CONNECTION

AIR VENT  
(ADDITIONAL PURCHASE)







# MAJESTIC

## CHAIR DIAGRAM

with optional

# AIR VENTS


**Note:** Not all chairs are equipped with Air Vents



## BACKVIEW OF BASE


### NOTE:

1ST DRAIN SHOULD BE AT 18 INCHES THERE AFTER, DRAINING SPACE SHOULD BE 36 INCHES






# MAJESTIC CHAIR DIAGRAM



68 in

Opening  
inside wall  
between  
chairs for  
connect  
plumbing


WALL



WALL

# GRAVITY DRAIN INSTALLATION

WALL



# DRAIN PUMP INSTALLATION

