

recozy⁺



Care Guide

A little care goes a long way.

Recozy design objects are characterised by circular design, functionality, and durability. To extend the lifespan of home accessories and furniture and to keep them in good condition for a long time, a little care goes a long way.

Floor vases & planters



Instructions for usage

Recozy floor vases are the perfect addition to any dried flower arrangement. Recozy planters come with a plant pot and drip trays for indoor plants, adding a vibrant touch to any interior.

General care instructions

Use a soft cloth to remove any loose dust. For stubborn grime, Recozy floor vases and planters can be cleaned with a damp cloth and lukewarm water.

If necessary, apply some mild soap to the cloth. The planters' plant pots and drip trays can be removed and cleaned similarly.

Recozy floor vases and planters can withstand heat up to 60°C (140°F). Make sure that Recozy design objects are not continuously exposed to sunlight.