

recozy⁺



Care Guide

A little care goes a long way.

Recozy design objects are characterised by circular design, functionality, and durability. To extend the lifespan of home accessories and furniture and to keep them in good condition for a long time, a little care goes a long way.

Furniture



Tips for protecting Recozy furniture

- + Always remove superficial grime quickly before it causes permanent damage to the furniture.
- + Use protective mats under pots or other hot objects to avoid burn marks on the furniture's surface.
- + Keep the furniture from intense heat sources like a fireplace to avoid material changes. Ensure that the furniture is not continuously exposed to sunlight.
- + Take care not to scratch or damage the surface with sharp objects.
- + Avoid improper use of the furniture, such as standing or jumping on it.

General care instructions

Use a soft cloth to remove any loose dust. For stubborn grime, Recozy furniture can be cleaned with a damp cloth and lukewarm water. If necessary, apply some mild soap to the cloth. All remaining moisture should be wiped away with a dry cloth.

Recozy furniture can withstand heat up to 60°C (140°F). Make sure that Recozy design objects are not continuously exposed to sunlight.

Digital product passport



To provide all customers with a high level of transparency regarding their design objects, we are collaborating with whatt.io. With this innovative, cloud-based product information platform, we aim to raise awareness for responsible resource management and promote sustainable purchasing decisions. This offers a clear summary of all product-specific information to all users.

At the bottom of the furniture piece is an NFC chip that allows access to the digital product passport. This provides a detailed insight into the manufacturing process, materials used, usage and care guidelines, and the recycling of the design object. Hold an NFC-capable smartphone next to the microchip and learn more about the Recozy furniture piece.