

recozy⁺



Care Guide

A little care goes a long way.

Recozy design objects are characterised by circular design, functionality, and durability. To extend the lifespan of home accessories and furniture and to keep them in good condition for a long time, a little care goes a long way.

Lighting



General care instructions

Use a soft cloth to remove any loose dust. For stubborn grime, clean the lampshade with a moist cloth. If necessary, apply some mild soap to the cloth. **Note:** Before cleaning, always turn off the electricity and remove the power plug from the outlet.

Recozy luminaires can withstand heat up to 60°C (140°F). Make sure that Recozy design objects are not continuously exposed to sunlight.

3-step dimming

To use the 3-step dimming of the lamp, operate the toggle switch on the textile cable. The LED light bulb's gradual dimming enables brightness adjustments of 100 %, 55 %, and 15 %, allowing for the creation of different light atmospheres.

Light Replacement

Consult the chapter „Light Replacement“ in the Operating and Safety Instructions to learn how to replace the LED light bulb.

Vases



Usage information

Recozy vases are equipped with a glass insert. This enables the submersion of bouquets in water. Dried flowers and similar decorations can be placed in the vase without the glass.

General care instructions

Use a soft cloth to remove any loose dust. For stubborn grime, Recozy vases can be cleaned with a damp cloth and lukewarm water. If necessary, apply some mild soap to the cloth. The vases are not dishwasher safe.

Recozy vases can withstand heat up to 60°C (140°F). Make sure that Recozy design objects are not continuously exposed to sunlight.

Glass insert

The glass insert of the vases can be removed and cleaned with lukewarm water, a small amount of cleaner, and a sponge. Light grime can be removed with a dry microfiber cloth and, if necessary, glass cleaner.

For stubborn grime, the glass insert can be removed from the vase and cleaned in the dishwasher.

We advise routine cleaning of the glass insert when it is no longer used, or the water is changed.

Floor vases & planters



Instructions for usage

Recozy floor vases are the perfect addition to any dried flower arrangement. Recozy planters come with a plant pot and drip trays for indoor plants, adding a vibrant touch to any interior.

General care instructions

Use a soft cloth to remove any loose dust. For stubborn grime, Recozy floor vases and planters can be cleaned with a damp cloth and lukewarm water.

If necessary, apply some mild soap to the cloth. The planters' plant pots and drip trays can be removed and cleaned similarly.

Recozy floor vases and planters can withstand heat up to 60°C (140°F). Make sure that Recozy design objects are not continuously exposed to sunlight.

Furniture



Tips for protecting Recozy furniture

- + Always remove superficial grime quickly before it causes permanent damage to the furniture.
- + Use protective mats under pots or other hot objects to avoid burn marks on the furniture's surface.
- + Keep the furniture from intense heat sources like a fireplace to avoid material changes. Ensure that the furniture is not continuously exposed to sunlight.
- + Take care not to scratch or damage the surface with sharp objects.
- + Avoid improper use of the furniture, such as standing or jumping on it.

General care instructions

Use a soft cloth to remove any loose dust. For stubborn grime, Recozy furniture can be cleaned with a damp cloth and lukewarm water. If necessary, apply some mild soap to the cloth. All remaining moisture should be wiped away with a dry cloth.

Recozy furniture can withstand heat up to 60°C (140°F). Make sure that Recozy design objects are not continuously exposed to sunlight.

Digital product passport



To provide all customers with a high level of transparency regarding their design objects, we are collaborating with whatt.io. With this innovative, cloud-based product information platform, we aim to raise awareness for responsible resource management and promote sustainable purchasing decisions. This offers a clear summary of all product-specific information to all users.

At the bottom of the furniture piece is an NFC chip that allows access to the digital product passport. This provides a detailed insight into the manufacturing process, materials used, usage and care guidelines, and the recycling of the design object. Hold an NFC-capable smartphone next to the microchip and learn more about the Recozy furniture piece.