




BCD 540 Battery Gun

W. ADAPTOR SOLUTION

Use your own battery with our new Badaptor. Badaptor enables you to use your DeWalt, Makita, Milwaukee or Bosch battery for the BCD 540 Battery Gun.

TECHNICAL INFO FOR BCD 540

- Cord-free gun for Ø12mm sticks
- Robust and reliable tool
- 100 watt gun
- Pre-adjusted temperature på 170 °C
- Ergonomic, lightweight tool
- Quick pre-heating
- Compatible with Dewalt, Makita, Bosch or Milwaukee Badaptor





 *Lithium batteries poison the environment so the fewer in circulation, the better.*



Badaptor



Handling & maintenance

 	 	 
<p>The gun must be placed in a standing position.</p>	<p>Never point the nozzle upwards. It destroys the chamber.</p>	<p>Never place the heated gun on the side. It destroys the chamber.</p>

▶ Handling

- ✓ Let the gun pre-heat for about 5-7 minutes
- ✓ Never pull a stick backwards from the gun!
- ✓ Never place the gun on the side and do not point upwards
- ✓ Only use recommended adhesives
- ✓ Keep the melting chamber free of dirt or dust
- ✓ Protect the device from moisture and liquids
- ✓ Check the battery status occasionally
- ✓ Check nozzle and change when necessary

▶ Claims

When we dismantle a gun, we can see what has caused the malfunction. In 99% of the cases, one of the below mentioned points has occurred, which are not valid reasons for complaint:

- 1. The gun was placed on its side, which destroys the chamber**
- 2. The gun and nozzle were held/pointed upwards for too long**
- 3. The gun was not heated enough before being put into use**
- 4. A stick was pulled backwards from the gun**

If you are convinced that none of the above-listed points have occurred, we will gladly check the tool in our workshop.