

Sebo XP10 User Guide

MANCHESTER
1824



- 1** Unpack the machine carefully, taking care to remove the sections from their polystyrene blocks and plastic wraps.



- 2** In the box you will find the machine in 4 major parts.: Head, body, hose and handle.



- 3** Attach the body in an upright position to the head until it clicks into place.



- 4** Push the handle into the top of the body - making sure the red triangle on the handle disappears into the body.



- 5** Twist lock on the upper section of the body anti-clockwise to close and secure handle in place.



- 6** Push the attachment tube handle into the body at the back.



- 7** Insert the hose into the body and push to click it into place.



- 8** All tools supplied stay on-board the vacuum when in use.



Video Guides

Please refer to the video for further guidance.
Scan for further details



Wray
Bros

Sebo XP10 User Guide

MANCHESTER
1824



- 9** Recline the handle and body by pressing down on the foot pedal.



- 10** The cord can be wrapped around a hook on the handle and a hand grip on the body.



- 11** If warning light comes on for bag. Pull handle up to release the vacuum bag compartment door.



- 12** Squeeze green side clips to pull the FA1693 vacuum bag out from the hinges.



- 13** Slide filter out to check for obstructions in case of blockage.



- 14** Pull hose out from socket and check for blockage. Remove obstruction if found.



- 15** If warning light comes on for brush, press side release button and remove casting from brush compartment.



- 16** Remove brush and check for obstructions, remove if necessary.



Video Guides

Please refer to the video for further guidance.
Scan for further details



Wray
Bros