

## Pro Switch 2 in 1 Ratchet Secateurs User & Care Instructions

**Thank you** for purchasing our Davaon Pro Switch 2 in 1 Ratchet Secateurs.

**Support**—Should you have any queries you can contact us 24/7 by sending a message via your Amazon account—Your Orders then click Contact Seller box next to your purchase. We aim to answer any questions within 2 hours of receiving your message.

To follow are some general care and user instructions:

**Note: Always take care when using tools with sharp blades. These are extremely sharp.**

### General Care Instructions

#### 1) CLEANING


- ⇒ If there is any oil on the blades, when you receive this, then please clean off using the oil sponge as seen below in the picture or with a soft cloth
- ⇒ Clean carefully after use using a damp soft cloth, or included oil sponge, to clean handle and blades ensuring you clean away from the sharp edges (NOT INTO THEM). Mind your fingers
- ⇒ Then dry using another cloth if required

#### 2) Ensure they are locked after use

#### 3) Oil lock and cutting mechanism from time to time

#### 4) STORE IN A SECURE, SAFE PLACE

#### 5) DO NOT OVER EXTEND the opening of the handles. The spring will open the secateurs to their intended width. Should you try to open then further to cut thicker than 22mm stems/branches then the spring may stretch and therefor no longer open as required. This will not be covered by warranty.



## Pro Switch 2 in 1 Ratchet Secateurs User & Care Instructions

**Note: Always take care when using tools with sharp blades. These are extremely sharp.**

### Opening & Closing Instructions

**Ratchet Secateurs lock by sliding the lock button over the lower part of the ratchet mechanism**

#### Unlock

- 1) Squeeze handles and move lock switch backwards with thumb or 2 fingers
- 2) It maybe a little stiff for the 1st few unlocks but this is normal

#### Lock

- 1) As above but move lock forwards

**NOTE: You may need to squeeze a little more to ensure the lower part of the ratchet mechanism is under the lock button**



### Switching From Ratchet to Single Cut Mode

**You have the option to choose between 'Ratchet' mode for thick branches and Single Cut mode, same as conventional pruner, if you are pruning smaller branches**

- 1) Squeeze handles together (lock if easier for you)
- 2) Move small switch on side until it clicks in place, as shown in image to select:  
R = Ratchet Mode - up to 22mm stems/branches  
S = Single Cut Mode - up to 18mm stems/branches

- 3) Open and use

#### UNIQUE 2 in 1 QUICK SWITCH—RATCHET TO SINGLE CUT MODE



**Ratchet Mode** — 4 Short Cut Ratcheting Action  
50% Effort Saving and great for thicker branches up to 22mm



**Quick Cut Single Cut Mode** — 1 Cut Conventional Cutting Action  
Great for branches up to 18mm when ratcheting action is not required



**New Ratcheting Mechanism**  
Switch from Ratchet to Single Cut Mode  
All you do is squeeze the pruner closed and flick the switch to R for Ratchet or S for Single Cut Mode  
Simple and Effective

## Pro Switch 2 in 1 Ratchet Secateurs User & Care Instructions

**Note: Always take care when using tools with sharp blades. These are extremely sharp.**

### How Ratchet Mode Functions

The 'Ratchet' mechanism helps to multiply your hands power. It clicks and moves to the next setting, after each squeeze & release. This increases pressure as you cut through so you don't have to do all of the work—the secateurs do it for you. Making this ideal for thicker branches.



**1)** Squeeze and Release 3 times—Each time the blade will slice through more and the ratchet will click to next level

**2)** After 3rd or 4th Squeeze your done

### Grip Examples



**Davaon®**

## **Pro Switch 2 in 1 Ratchet Secateurs User & Care Instructions**

### **Davaon Garden Tools Range**

Why not check out the rest of our Davaon Garden Tools Range on Amazon:

**Just search DAVAON in the Amazon search bar**

