



MEAWATER®



IRIS 1/2" **INSTALLATION INSTRUCTIONS** UNDER-SINK & SHOWER

This device is designed for one tap use and can be installed under your sink, on your shower, sprinkler, or garden taps. Check the set-up of the sink or shower systems to ensure there is space and a connection point for the IRIS device.

Step 1: Determine the location to install your IRIS device using the parameters below:

- The IRIS device can be installed in a horizontal or vertical position.
- The device should be installed at least 1 metre away from electrical motors to avoid any electromagnetic interference.

Step 2: In some situations, you may need fittings for connections between the IRIS device and the pipe or under-sink hose. The thread size is 1/2" with a male-end thread. Attach plumber's tape to the male-end of the device.

Step 3: For under-sink installations, locate the cold-water hose. Generally, it has a blue thread. Turn off the water supply. Disconnect the nut on the cold-water hose at the tap end.

Step 4: Disconnect the cold-water hose from the water inlet end and insert the male-end of the IRIS device, ensuring the connection is tight.

Step 5: Insert the cold-water inlet hose (male-end) into the female-end of the device, ensuring the connection is tight.

Step 6: Reconnect the nut at the tap end of the hose, ensuring the connection is tight. Switch the water back on, test the connections for any leakages.

Installation for shower systems

Depending on the shower system, you can install the IRIS device on top of the shower rose or at the water input end. Consult a handyman or plumber if necessary.

Installation for a sprinkler or tap

Standard connectors can be purchased from your hardware store to install the IRIS device on a sprinkler, indoor or outdoor tap.

Enjoy all the benefits of your MEA water device!

*Please contact MEA water for any further installation instructions:
info@meawater.com or phone +61 2 4842 8182*