



## INSTALLATION INSTRUCTIONS

**PART No.** 30412 & 30521, 50412 & 50521



**MODEL No.**



## INSTALLATION INSTRUCTIONS

**PART No.** 30412 & 30521 50412 & 50521

**MODEL No.**



Remove the pull knobs by pushing the release clip at the bottom of each knob. Place the gauge cover in position mark the four mounting holes using a magic marker. Drill with a 1/8" drill bit and then fasten using the stainless screws provided. Reinstall the pull knobs by pushing them on the proper shaft.

Remove the pull knobs by pushing the release clip at the bottom of each knob. Place the gauge cover in position mark the four mounting holes using a magic marker. Drill with a 1/8" drill bit and then fasten using the stainless screws provided. Reinstall the pull knobs by pushing them on the proper shaft.