




INSTALLATION INSTRUCTIONS

PART No. 30412 & 30521, 50412 & 50521

MODEL No.




Remove the pull knobs by pushing the release clip at the bottom of each knob. Place the gauge cover in position mark the four mounting holes using a magic marker. Drill with a 1/8" drill bit and then fasten using the stainless screws provided. Reinstall the pull knobs by pushing them on the proper shaft.



INSTALLATION INSTRUCTIONS

PART No. 30412 & 30521, 50412 & 50521

MODEL No.



Remove the pull knobs by pushing the release clip at the bottom of each knob. Place the gauge cover in position mark the four mounting holes using a magic marker. Drill with a 1/8" drill bit and then fasten using the stainless screws provided. Reinstall the pull knobs by pushing them on the proper shaft.