



INSTALLATION INSTRUCTIONS

PART No. 30526, 50526



INSTALLATION INSTRUCTIONS

PART No. 30526, 50526



Place a very small screwdriver in the square hole at the top of the key lock mechanism. Push down on the retaining clip while pulling on the cylinder of the key lock. Once the cylinder is loose put the key in to prevent the tumblers from falling out. To reinstall the key lock, with the key in the cylinder slide the tumbler into the housing and remove the key.

Place a very small screwdriver in the square hole at the top of the key lock mechanism. Push down on the retaining clip while pulling on the cylinder of the key lock. Once the cylinder is loose put the key in to prevent the tumblers from falling out. To reinstall the key lock, with the key in the cylinder slide the tumbler into the housing and remove the key.