

SAFETY INSTRUCTIONS

Please read the User Manual carefully before using the LOKITHOR J401 multi-function startup power supply

1. Please operate in strict accordance with the instructions, improper operation may lead to serious safety accidents.
2. The starting power supply is only used to start the 12V engine, and cannot start vehicles that exceed the specified displacement or exceed the specified voltage (12V).
3. Forced start mode, in this mode, part of the safety protection mechanism is invalid. Please use with caution, be sure to prevent short circuit to connect wrong with positive and negative poles, otherwise it may cause accident. Please check the operating instructions carefully before operation
4. In order to prolong the service life of the internal battery, please charge the device in time when you get it, and charge and discharge the device every three months to ensure that the starting power is in good condition for the next use.
5. Do not use the product that has been excessive shocked, dropped or other forms of damage.
6. Do not disassemble the product. Please contact professional maintenance personnel to repair and handle the abnormal product.
7. Do not use the product to start the vehicle while the product is in charging.
8. Be careful during operation to avoid metal tools falling on product interface (it may cause short circuit, equipment damage and explosion).
9. When using the product, ensure that the surrounding area of the starting power supply is well ventilated.
10. When jump starting the car, make sure that the positive and negative poles of the cable are in good contact with the positive and negative poles of the car battery.
11. Prohibit sparks, flames near the product and car engine.
12. In order to prevent short-circuit sparks from damaging the product, it is forbidden to connect the positive with negative clamps together or contact the same metal.
13. Do not place the starting power supply where children can easily touch it.
14. Do not expose the product to rain and snow.
15. Do not place the device in extreme environments for a long time (such as high temperature: greater than 131°F (55°C), extreme cold: less than 14°F (-10°C), humidity: humidity > 80%).
16. Please store the product in a cool and dry place, and take protective measures when necessary.
17. When the product power is exhausted or in low power, please charge it in time to prevent battery undervoltage. Long-term zero-voltage states may cause the product to fail to charge.

PRECAUTIONS

There is no maintainable part of the device for user. Do not disassemble the product. Any maintenance should be handled by professional maintenance personnel.

Precautions :

1. When over 50% capacity, the product can be used to start the vehicle quickly, with insufficient power may not be able to start the vehicle effectively;
2. It is normal for the body to heat up after the product is turned on.
3. In order to maximize the product cycle life, please charge it at least once every 3 months.
4. If the product leaks or emits any odor when turn on, please stop using it and contact Lokithor customer service immediately.
5. Do not connect the red clamp to the black clamp, it may cause danger.
6. Please only use the original clamps.
7. Please keep the product away from fire and water to avoid accidents.

8. Do not place the product in an environment above 60°C or expose it to sunlight; please store the unit in a cool and dry place.
9. Do not disassemble or modify this product without authorization.
10. Do not hit, press or shake violently to start the product, otherwise it may cause fire, explosion and combustion
11. Do not use chemical cleaners to clean the product.
12. Keep this product away from children.

HANDLING & RECYCLING

- 1. Do not dispose of it with other household waste to prevent irreparable harm to the environment or humans.**
- 2. Please separate it from other types of waste and recycle it responsibly to promote the sustainable use of material resources.**

WARRANTY

For any defects in material and workmanship, 12 months warranty offered from the date of purchase by the user, subject to the following conditions:

1. The purchaser must provide the receipt proof (order page details/invoice, etc.) of the regular dealer channel to apply for after-sales.
2. The warranty does not cover damage or malfunction caused by normal wear and tear, physical damage, improper installation, misuse, modification or repair by unauthorized third parties.
3. Any loss or damage caused by a third party in transit or due to majeure will not be warranted.
4. Any incidental or consequential damage caused by misuse will not be warranted.
5. All warranty claims are limited to repair or replacement of defective products at our sole discretion.
6. If repair or replace the product, the product will cover the remainder of the original warranty period. Repairs or replacements may involve the use of functionally identical refurbished equipment, returned products or accessories, at our discretion.
7. Consumable parts such as batteries are not covered by the warranty.
8. The final change and interpretation right of the warranty regulations belongs to the merchant.

Contact LOKITHOR

TEL: 925-364-7166

EMAIL: lokithorstore-us@hotmail.com

Address: 290 Lindbergh Ave Livermore, CA 94551 US