



Scroll Wheel Button DPI Switch Button


Charging Indicator Light/
Low Battery Indicator Light


Type-C Charging Port


USB Indicator Light
 Mode Switch Button





















Before pairing, please operate the Bluetooth mode installation procedures ①②.


4 Click "Settings" on your device and turn on "Bluetooth".

Before pairing, please operate the Bluetooth mode installation procedures ①②.



Before pairing, please operate the Bluetooth mode installation procedures ①@

4 Click "Settings" on your device and turn on "Bluetooth".



After are connected, short press the channel key on the keyboard, easily switch between multiple devices.	Keys	Windows OS	Android OS	iOS	Mac OS
Bluetooth 1 Device Connection	*	Light -	Light -	Light -	Light -
Bidetooth i Device Connection	*	Light +	Light +	Light +	Light +
	밂	Window Switch	Window Switch	Window Switch	Window Swite
○ -\  - ○   - ○	000	Application Switch	Application Switch	Open latest Window	Open latest Wir
		Display Desktop	Go Home	Go Home	Go Home
	٩	Search	Search	Search	1
	N	Previous Track	Previous Track	Previous Track	Previous Trac
(B) *1 *2 (D) (B) *1 *2	DII	Play & Pause	Play & Pause	Play & Pause	Play & Paus
2.4G Mode Connection  Bluetooth 2 Device Connection	DI	Next Track	Next Track	Next Track	Next Track
Soffice Confidence	d×	Mute	Mute	Mute	Mute
Keyboard Charging	(۲	Volume -	Volume -	Volume -	Volume -
	<b>◁»</b> )	Volume +	Volume +	Volume +	Volume +
	٥	Setup	Setup	Setup	Setup
	4	Lock Screen	Lock Screen	Lock Screen	1
	0	Screenshot	Screenshot	Screenshot	Screenshot
When the battery is too low, the low battery indicator will turn red and flash	<b>⋒</b>	FN+ESC (FN lock) button to turn on or turn off the FN function			

		Product Parameter	s	Bluetooth Transmission Parameters:	Bluetooth Transmission Param			
				Transmission Distance 10m	Transmission Distance			
		Keyboard Parameters:		Working Voltage 3.7V	Working Voltage			
	Mac OS	Battery Capacity	210 mAh	Working Current <5mA	Working Current			
	Light -	Working Current	≤ 3.5 mA	Polling Rate 125Hz	Polling Rate			
	Light			System Requirements Bluetooth receiving device	System Requirements			
	Light +	Sleep Current	31 uA	Windows 8, Windows 10 or higher vers		ersion		
		Charging Current	190 mA (±20mA)	Mac OS X 10.10 or higher version				
ch	Window Switch	Standby Current	≤ 0.3 mA	Android 4.3 or higher version				
dow	Open latest Window	Standby Time	≥ 150 Days					
ldow Opc		Charging Time	< 2 Hours	Tips				
	Go Home	Wake Up Way	Press any key					
	_	Weight	297 g	1. If it fails to connect normally, it is recommended to turn off the keyboard	1. If it fails to connect normally,	ırd		
	/	Keyboard Dimension	386.4x119.7x12.4mm(Unfolded) 215.5x119.7x20.9mm(Folded)	power, restart the Bluetooth of the device and connect again. Or delete the extra Bluetooth option name in the Bluetooth connection list of the device	• •			
ck	Previous Track		21010/11011/1201011111(1101004)	reconnect.	·	Cana		
е	Play & Pause	Mouse Parameters:		To switch to a channel that has been successfully connected, first press				
	-	Engine	Optics	channel button firstly, and then wait 3 seconds to keep working.	•			
	Next Track	DPI	1000/1600/2400 DPI	3. The keyboard mouse has memory function, when the keyboard mouse	•			
Mu	Mute	Mouse Button Life	More than 3 million times	connected properly at one channel, turn off the keyboard mouse and turn of		•		
	Wate	Battery Capacity	300mAh	again, the keyboard mouse will be in the default channel, and the indicator	this channel is on.			
	Volume -	Battery Life	1000 times charge and discharge cycles	this channel is on.				
	Volume +	Standby Time	200 Days	Sleep Mode	Sleen Mode			
	volume +	Continuous Working Time	50 hours	Olecp Mode	Olecp Mode			
	Setup	Mouse Dimensions	107.9*59.1*20.1mm	1. When the keyboard is not used for more than 30 minutes, it will	· ·			
1	1	2.4G Transmission Parameters	): :		automatically enter the sleep mode and the indicator light will be off.  2. When you use the keyboard again, you only need to press any key, and the			
	Screenshot	Transmission Distance 10m			keyboard will wake up within 3 seconds. The indicator will light up again and			
	Corcononot	Working Voltage	3.7V	starts to work.	starts to work.			
nctio	1	Working Current	<5mA					
		Polling Rate	250Hz	Packing List	Packing List			
ned	ia functions are	System Requirements	An available USB port Windows XP, Windows 7, Windows 8, Windows 10 or higher version	► 1* Wireless Bluetooth Keyboard  ► 1* Hard Carrying Case  ► 1* Wireless Bluetooth Mouse  ► 1* Phone Holder  ► 1* Time C. Charging Cable  ► 1* Hard Manual	► 1* Wireless Bluetooth Mouse			