




As a Safety Precaution, **ONLY** adjust V-Stand® Pro height when there is **NO** keyboard on the stand.

V-STAND® PRO

KEYBOARD STAND

Manual




Visit ultimatesupport.com
to download a detailed
product manual, read full
warranty details and to
register for warranty.

LIMITED LIFETIME WARRANTY
Go to ultimatesupport.com for More Details




V-STAND® INSTRUCTIONS


1. Lay stand on floor in folded position. Separate both legs outward until they stop.



2. Secure legs in open position with locking pins.




3. Pull vertical struts upward to a vertical position and spread them to their open position.




V-STAND® INSTRUCTIONS

4. Move support arms into their horizontal position by swinging them up and over the vertical struts.



5. Secure arms in horizontal position with locking pins.



6. Raise or lower inner strut to desired height and push, or rotate, locking pin collar into locking position.

