



Visit ultimatesupport.com to download a detailed product manual, read full warranty details and to

LIMITED LIFETIME WARRANTY
Go to ultimatesupport.com for More Details



## ADJUSTABLE ANGLE FEATURE (MC-FT-200)

To adjust the angle of the mic stand, press down on the adjustable angle foot pedal control. While pushing down on the adjustable angle foot pedal, pull mic shaft towards desired angle. The mic shaft will lock in 0° and 10° positions.



There are two holes in the mic base. One is 0° and the other is 10°. To change angle of mic stand, unscrew mic shaft from stand, remove plug from desired hole and screw mic shaft into desired hole. For storing plug, screw into open hole.







