



# HYPERSTATION QR FEATURES & CONFIGURATIONS

## ADJUSTING ARM LENGTH




## SECURING LAPTOP

To adjust support thumb, pulling out and turn.



Secure the laptop by rotating the figure knob and pushing figure clamp over laptop, then tighten figure knob again to lock into place.




## ADJUSTING ARM ANGLE

To Adjust the angle: loosen the arm knob and change the angle. Then tighten knob at desired angle.


Two adjustable clips for cable management.

Adjustable knob locks the stand body in both folded and standing positions.



Visit [ultimatesupport.com](http://ultimatesupport.com) to download a detailed product manual, read full warranty details and to register for warranty.


# ULTIMATE SUPPORT®



**HYPERSTATION QR**  
LPT-1000 QR, 17510

**HYPERMOUNT QR**  
HYM-100 QR, 17511

## MANUAL




Additional HyperStation QR Configurations


**LIMITED LIFETIME WARRANTY**  
GO TO [ULTIMATESUPPORT.COM](http://ULTIMATESUPPORT.COM) FOR MORE DETAILS




# HYPERSTATION QR EXPANDING AND COLLAPSING




**1.** HyperStation QR set up with adjustable tray.




**2.** Remove or adjust tray by lifting up, than pulling out.




**3.** Lay tray down on feet for collapsing stand.



**4.** Lengthen both arms by losing extending knobs. Move support thumb forward by pulling out and turning.




**5.** Loosen the arms and body knobs. Pull arms back while lowering the body.



**6.** Screw body knob into base. Tighten the arm & extending knobs. Slide stand into bag.

# HYPERSTATION QR EXPANDING CONFIGURATIONS



To transform the HyperStation QR into any of the four positions pull down on the QuickRelease and left. The QuickRelease will need to be added to the mic and keyboard stand. The included t-shaped adapter is needed for the tabletop configuration.

