


FEATURES

IQ-X-3000, IQ-X-2000 & IQ-X-1000



1. With the Memory Lock facing you, hold top left tube with left hand and with your right hand pull the Memory Lock knob toward you. Being sure to fully retract the pin from the Memory Lock plate.



2. Holding the extracted Memory Lock knob with right hand, pivot the "X" brace with left hand to desired height and release knob. Be sure the Memory Lock is fully and securely engaged before placing keyboard on stand.

NOTE: Your IQ-X-1000, IQ-X-2000 and IQ-X-3000 will open to this height every time you use it unless a new height is desired.




Arms and legs feature adjustable leveling end caps. Turn the leveling end caps as needed to adjust for uneven surfaces.

Visit ultimatesupport.com to download a detailed product manual, read full warranty details and to register for warranty.


ULTIMATE SUPPORT®

IQ SERIES® KEYBOARD STAND


Manual



IQ-X-3000



IQ-X-1000




IQ-X-2000

LIMITED LIFETIME WARRANTY
GO TO ULTIMATESUPPORT.COM FOR MORE DETAILS



ASSEMBLING STAND

IQ-X-3000, IQ-X-2000 & IQ-X-1000



ATTACHING FEET (FIRST)

Make sure that the feet are placed on the bottom of the stand. The bottom is below center bolt.

Place feet on by lining up matching numbers. Make sure the long end of each foot is facing front.

Attach provided screws & washers. Screws attach from the outside.

ATTACHING ARMS (SECOND)

Make sure that the Arms are placed on the top of the stand. The top is above adjustment knob.

Place arms on by lining up matching numbers. Make sure the long end of arms is facing front.

Attach use provided screws and washers. Screws attach from the outside.