

## Features


IQ-3000, IQ-2000 & IQ-1000



The bottom and top of the X-Stand supports feature adjustable leveling end caps. Turn the leveling end caps as needed to adjust for uneven surfaces.


Available second tier for the IQ-1000 & IQ-2000

(Sold Separately)



Available second tier for the IQ-3000



(Sold Separately)



# ULTIMATE SUPPORT®

## IQ SERIES® KEYBOARD STANDS

### Manual




Visit [ultimatesupport.com](http://ultimatesupport.com) to download a detailed product manual, read full warranty details and to register for warranty.

LIMITED LIFETIME WARRANTY  
Go to [ultimatesupport.com](http://ultimatesupport.com) for More Details



# SETTING MEMORY LOCK


## IQ-3000



1. Turn the z-knob counter clockwise to spread apart memory lock teeth. Both sides of the memory lock should turn freely if teeth are spread apart enough.




2. Make sure that both ribbed catches are pushed out away from center of memory lock.



3. Open the stand to the desired position.




4. Again, make sure that both ribbed catches are pushed away from center of memory lock.



5. Line up teeth so that they interlock and turn z-knob clockwise to lock in place.

# SETTING MEMORY LOCK

## IQ-2000 & IQ-1000



1. With the Memory Lock facing you, hold top left tube with left hand and with your right hand pull the Memory Lock knob toward you. Being sure to fully retract the pin from the Memory Lock plate.



2. Holding the extracted Memory Lock knob with right hand, pivot the "X" brace with left hand to desired height and release knob. Be sure the Memory Lock is fully and securely engaged before placing keyboard on stand.

**NOTE:** Your IQ-1000, IQ-2000 and IQ-3000 will open to this height every time you use it unless a new height is desired.