


ULTIMATE
SUPPORT®

FLY POINT LIGHTING BAR

Manual



Visit ultimatesupport.com
to download a detailed
product manual, read full
warranty details and to
register for warranty.




LIMITED LIFETIME WARRANTY
Go to ultimatesupport.com for More Details



ATTACHING TO SPEAKER


Preparing Speaker

Remove the speaker's existing fly points screws from mounting holes.




Placing Pole on Speaker

Using mounting holes on speaker and the two provided screws to attach lighting bar. We have included M10 x 1.5mm bolts as standard mounting hardware for the LT-48FP. While this will be sufficient for the majority of fly points, the bolts may be too long for the fly-points on some speakers. Two optional washers are provided to accommodate speakers with those specifications.



ATTACHING LIGHTS



The Fly Point Mountable Lighting Bar includes its own hardware for mounting lights. Use the diagram above to attach the lights on either side of the speaker.