



SM-FS Floor Stand for Sonos Move



The perfect place to charge and listen to the Sonos Move. The speaker is held securely, and is easily removed when you want to take it outside.

- Bespoke design securely holds the Sonos Move and the charging base
- Sonos Move can be charged while on the floor stand
- Sonos Move easily removed when you want to take it outside
- Positions the speaker at ideal height for seated listening
- Quick and easy assembly
- Includes adjustable carpet spikes and rubber feet for wood/tiled floors
- Clever cable management to keep things tidy
- Constructed from steel and aluminium
- Designed and manufactured in the UK



Product Code	FLXSMFS1051
UPC Number	5057964001821

Millimetres / Kilograms	Height	Width	Depth	Weight
Product Size	950	260	277	4.68
Millimetres / Kilograms	Length	Width	Height	Weight
Retail Carton	675	290	65	5.45
Carton Contents	1 x floor stand and instructions			
Outer Carton Quantity	4	Country of Manufacture	UK	

Sonos is a registered trademark of Sonos Inc. Flexson is not affiliated with Sonos Inc.